ACC queue assist.....160
ACC radar detection beam issues...162
ACC set speed and follow mode override.....160
activating intelligent stop/start.....124
active differential.....132
active exhaust.....123
adaptive cruise control.....158
after a collision.....325
arduous conditions.....252
automatic speed limiter.....156
before starting.....325
blind spot monitor.....74
  closing vehicle sensing.....75
blind spot monitor messages.....76
brake control with ABS.....138
brakes important information.....138
daily checks.....251
deactivating intelligent stop/start....125
DSC active warning lamp.....60
electronic brake force distribution...139
emergency brake assist.....139
emergency stop signal.....140
forward alert.....163
forward alert warning lamp.....62
gear shift warning lamp.....62
hill start assist.....140
lane departure warning lamp (green).....62
lane departure warning lamp (red)....59
low oil pressure.....59
park assist limitations.....152
park assist troubleshooting.....153
progress control settings.....166
progress control system overview...165
rain sensor.....70
resume ACC follow mode.....161
resume ACC set speed.....161
running-in.....251
selecting park assist.....151
sitting correctly.....22
steep slope control with ABS.....138
using ACC.....158
using cruise control.....157
  using the progress control system...165
  weekly checks.....251
Driving abroad
  beam pattern.....66
  headlamps.....66
Driving aids
  lane departure warning.....141
  traffic sign recognition.....143
Driving assist.....142
Dual view.....198
  controls.....198
Dynamic response
  fluid level.....277
  fluid specification.....278
  fluid top up.....278
Dynamic stability control (DSC).....131
  DSC active warning lamp.....60
  DSC off warning lamp.....60
  switching off.....131
  switching on.....131

E

Easy route.....229
Eco-data controls.....126
Effects of battery disconnection.....282
Electric mode.....116
Electric parking brake.....139
Electric seats.....21
  access to rear.....26
  head restraint removal.....30
  head restraints.....29
  passenger seat away.....25
  position memory.....23
  restricted front seat travel.....22
Electric windows
  operation.....81
Electronic brake force distribution.....139
Electronic data.....325
Email
  InControl connection.....219
Emergency (navigation).....231
Emergency brake assist.....139, 163
Emergency call
  InControl link.....215