

Steering wheel

Full steering assistance should return when the system has been allowed to cool. If full steering assistance does not return, consult a Retailer/Authorised Repairer.

HEATED STEERING WHEEL



Press the button to switch the heated steering wheel feature on and off. An amber indicator will illuminate when the heated steering wheel feature is on.