

# Steering wheel

Full steering assistance should return when the system has been allowed to cool. If full steering assistance does not return, consult a Retailer/Authorised Repairer.

## HEATED STEERING WHEEL



Press the button to switch the heated steering wheel feature on and off. An amber indicator will illuminate when the heated steering wheel feature is on.