


MAP SPLIT SCREEN



E153266

1. Compass (always indicates north):
Press to select: north up, heading up or bird's eye map style.
 2. TMC (Traffic Message Channel) signal:
Without a diagonal bar, a signal is being received; with a diagonal bar, a signal is not being received. The icon will also change colour depending on the status of traffic on the route.
 3. Next direction display: When Junction map view has been switched off, touch the icon to view again.
 4. Current vehicle position and direction.
 5. Right map view, scale/zoom setting.
 6. Current location.
 7. GPS signal indicator: The indicator is only displayed when there is no reception.
 8. Screen mode.
 9. Left map view, scale/zoom setting.
 10. Opens the Navigation menu; 1 of 2 screens.
 11. Distance/time/ETA (estimated time of arrival) to the destination.
 12. TMC event (traffic congestion).
-  Touch to close the Junction and Motorway junction mode. The previously displayed map is shown after closing.

MAP AUTO ZOOM

When under guidance, the map zooms in automatically when approaching a road junction or motorway junction.

1. From the map screen, touch the left map view, scale/zoom soft key.