
MAP SPLIT SCREEN



1. Compass (always indicates north): Press to select: north up, heading up or bird's eye map style.
2. TMC (Traffic Message Channel) signal: Without a diagonal bar, a signal is being received; with a diagonal bar, a signal is not being received. The icon will also change colour depending on the status of traffic on the route.
3. Next direction display: When Junction map view has been switched off, touch the icon to view again.
4. Current vehicle position and direction.
5. Right map view, scale/zoom setting.
6. Current location.
7. GPS signal indicator: The indicator is only displayed when there is no reception.
8. Screen mode.
9. Left map view, scale/zoom setting.
10. Opens the Navigation menu; 1 of 2 screens.
11. Distance/time/ETA (estimated time of arrival) to the destination.
12. TMC event (traffic congestion).



Touch to close the Junction and Motorway junction mode. The previously displayed map is shown after closing.

MAP AUTO ZOOM

When under guidance, the map zooms in automatically when approaching a road junction or motorway junction.

1. From the map screen, touch the left map view, scale/zoom soft key.