

Note: This 3.5mm AUX socket allows extra equipment (e.g., personal stereos MP3 player, hand-held navigation unit, etc.) to be connected to the Media system.

3. Rear media AV sockets.
4. Rear media USB/iPod socket.

When an iPod is connected, playback will continue from the point at which it was last playing, provided the iPod battery is in a good state of charge.

Note: Options, such as **Repeat** and **Mix**, relate to the device currently playing; they will not apply to any subsequent device.

Note: iPod shuffle may be connected via the AUX socket.

Note: On vehicles fitted with Rear media, extra audio/visual sockets are provided. This allows auxiliary equipment to be linked to the Rear media screens. For installation information, please refer to the manufacturer's instructions.

PLAYING A PORTABLE DEVICE

If you are using a USB mass storage device, or an approved iPod, playback can be controlled using the Touch screen.

Note: iPod is a trademark of Apple Inc., registered in the US and other countries.

If you are using a **Bluetooth®** wireless technology device, you can control playback using the Touch screen, but some controls are unavailable.

If you are using any portable media device via the AUX socket, then you must control playback from the device itself.



It is not recommend the use of an external Hard Disc Drive (HDD), connected via the USB link, while the vehicle is in motion. These devices are not designed for in-car use and may be damaged.

CONNECTING MULTIPLE DEVICES



Do not plug non-audio devices into the USB port.

You can connect multiple devices simultaneously to the portable media interface and switch between them using the Touch screen. Select **iPod**, **USB**, **Bluetooth**, or **AUX**, to switch between modes.

The device docked first will remain the active device until you choose to change.

If, after changing to the newly-docked device, you change back to the first device, play will resume at the point you left it (USB and iPod only).

Note: You cannot use a USB hub to connect more than one USB device to the Media unit.

Note: Devices connected to the iPod and USB ports will be charged, but devices that are fully discharged will not play.

Note: Options, such as **Repeat** and **Shuffle**, relate to the device currently playing; they will not apply to any subsequent device.

PAIRING AND CONNECTING USING THE MEDIA PLAYER

For further information on **Bluetooth®** wireless technology, see **209, BLUETOOTH® INFORMATION**.

Note: The process of pairing and connecting a media device with the vehicle, using the media device, will vary depending on the type of media device.

1. Switch on the ignition and make sure the Touch screen is active.
2. From the **Home menu**, select the Media soft key, then select the **My music** and **Source +** soft keys.
3. Select **Bluetooth**.
4. A menu will appear. Select **Change device**.
5. Select the **Device to vehicle** option.

Note: The vehicle's **Bluetooth** wireless technology system is only discoverable for 3 minutes.

6. Using the media device, search for **Bluetooth** wireless technology devices. On some media devices, this is referred to as a new paired device. See the media device's operating instructions for further information.
7. When the vehicle's **Bluetooth** wireless technology system is discovered, follow the on-screen instructions. Select **Yes**, when prompted, to confirm the pairing. Either the device, or the vehicle's system will ask for a PIN (Personal Identification Number). When prompted, enter a PIN of your choice and select **OK** to confirm.
8. Enter the same PIN into the other device.
9. Once the device is paired and connected to the system, a confirmation message will be displayed, before switching back to the **Bluetooth** screen.

Note: Some media devices do not automatically connect and need to be manually connected via the device or by using the **Change device** option.