



Phone battery level indicator.



Bluetooth: Indicates that a **Bluetooth®** wireless technology device is connected.



Tick: Indicates that a **Bluetooth** wireless technology device is paired.



Voicemail: Press and hold to dial the stored voicemail number.



Scroll bar up arrow: Use to scroll up lists of detected phones, calls or phonebook entries.



Scroll bar down arrow: Use to scroll down lists of detected phones, calls or phonebook entries.

STEERING WHEEL CONTROLS



E 1109346

1. Press to scroll back through received calls, the Last 10 dialed list, and finally to exit the list.
2. Increase the volume when in a call, scroll up a displayed list or number listed for a stored contact.

3. Press to scroll to the Last 10 dialed list and received calls.
4. Decrease the volume when in a call, or scroll down a displayed list or a number listed for a stored contact.
5. Press to answer an incoming call. Press to end a call. Press and release to dial a number/contact. Press and release to access the Last 10 dialed list. Press and hold to access the Phonebook list view.

Note: When scrolling through a Phonebook or the Last 10 dialed list, each contact is also displayed in the Message centre.

Note: In order to scroll through a list, the 'phone' button (5) must first be pressed.

CALL VOLUME

The vehicle's phone call volume is set by use of the media controls, on the audio/video unit. See **175, AUDIO/VIDEO CONTROLS**.

If a media source is in use when a phone call is active, the media source is suppressed for the duration of the call.

PHONEBOOK

Contacts stored in the memory of a paired phone can be automatically downloaded to the vehicle's Phonebook each time the phone is connected to the system. See **211, TELEPHONE COMPATIBILITY**.

Certain phones store their phonebook in two different areas; the SIM card and the phone's memory. The vehicle's system will access only those numbers stored in the phone's memory.

To access contacts from the phonebook:

Telephone

1. From the **Phone** menu, select **Phonebook**.
2. Using the on-screen keyboard, select the letter you wish to search under.
3. Select **List** to view the Phonebook.
4. Identify the required contact from the displayed list and touch to call. If a contact has more than one number stored, select the required number from the list.

Note: *It may be necessary to use the scroll bar to see the entire list.*

There are also options to view more contact information, by selecting the corresponding **i** key.

If your phone supports contact type data, you will be able to see a contact type icon in the vehicle's Phonebook directory. These can be seen on the right side of each contact in the directory and will indicate one of the following types:



Default.



Mobile.



Home.



Work.