

AFTER TOWING ON FOUR WHEELS

1. Apply the Electric Parking Brake (EPB).
2. Switch on the ignition and apply the brake pedal.
3. Rotate the gear selector to Park (P).
4. Deactivate the Transmission park release mechanism.
5. Switch off the ignition and remove the Smart key from the vehicle.
6. Remove the recovery vehicle's towing attachment from the front towing eye and refit the cover.



Use extreme caution when detaching towing equipment. Vehicle movement is possible, which can result in serious injury.