

- Short touch to find the next available channel.
 - Long touch to find the next available ensemble. The first channel in the new ensemble will be selected.
6. **Settings:** Touch to view the **DAB Settings** menu:
- **Options:** To activate/deactivate **FM Traffic** and **Link DAB** and to alter **DAB country** and **DAB format** settings (with vehicle stationary).
 - **Announcements:** Select an alarm announcement and up to 3 other announcement types (**traffic**, **news**, etc.) from the list. The selected announcements will interrupt the current programme, when broadcast.
7. **Channel list:** Touch to view a list of available ensembles and channels. The list can be sorted by **Ensemble**, **Channel**, **Subchannel**, or by **Category**.
- If an **Ensemble** is selected from the list, all available channels from that ensemble will be displayed.
 - Sorting by **Subchannel** is only available when the current channel is broadcasting subchannels.
 - If **Category** is selected, touch the chosen category to view corresponding channels, before making your selection from the list.
- Once the desired selection has been made, select the Back soft key to return to the main DAB menu.
8. **Subchannel:** If subchannels are broadcast by the current channel, this soft key will be active. Select to allow subchannels, then select the required subchannel with the seek down/up keys.
9. **Auto-tune:** Select to scan for all available DAB ensembles/channels. This needs to be done before using the DAB radio for the first time. Auto-tune is also useful when travelling long distances, so regional ensembles can be tuned. During auto-tuning, a pop-up shows tuning progress. The auto-tune process will not affect any current presets, but some presets may not operate if the channel they relate to is no longer available (**No reception** displays).
10. **Presets:** Each DAB presets page has 6 preset positions where channels can be stored.
- Touch and release to tune the radio to the station stored on that preset.
 - Touch and hold to store the current station on that preset (the radio will mute while the station is stored).
 - Use the seek buttons on the steering wheel to select the next or previous preset station.
- Note:** If you attempt to select a preset channel that is now unavailable or invalid, **No reception** is displayed.*

DAB RADIO SETTINGS

In **Settings**: