

- Vehicle battery
    - battery monitoring system.....283
    - connecting jump leads.....280
    - effects of disconnection.....282
    - removing.....282
    - replacing.....282
    - warning symbols.....279
  - Vehicle battery care.....279
  - Vehicle cleaning
    - after driving off-road.....267
    - airbag covers.....270
    - alloy wheels.....268
    - engine compartment.....266
    - interior.....268–269
    - under body.....266
    - washer jets.....270
  - Vehicle data recording.....325
  - Vehicle loading tyre pressures.....305
  - Vehicle location
    - InControl secure.....219
  - Vehicle recovery
    - front towing eye.....319
    - off-road.....322
    - rear towing eye.....319
    - steering column lock.....9
    - towing on four wheels.....322, 324
    - transmission park release.....321
    - transporting the vehicle.....322
    - unlocking the steering column.....322
  - Vehicle storage.....252
  - Vehicle testing on rolling roads.....254
  - Video media player
    - controls.....196
    - dual view.....198
      - controls.....198
      - headphones.....199
    - full screen view.....197
    - headphones.....203
    - inhibited display.....197
    - rear media touch screen control....200
    - rear media use.....202
  - VIN number.....327
  - Voice control.....205
    - navigation POI categories.....207
    - recognising your voice.....206
    - settings
      - command list.....207
      - operating guide.....207
      - preferences.....207
      - voicetags.....207
      - voice training.....207
    - training the system.....206
    - tutorial.....206
    - voicetags.....207
  - Voice guidance.....229
  - Volume
    - telephone.....213
- ## W
- Wade sensing
    - controls.....173
  - Wading depth
    - touch screen aid.....173
  - Warning lamps.....58, 61–62
    - ABS.....60
    - ACC follow mode.....61
    - adaptive front lighting system (AFS).....60
    - airbags.....48, 60
    - automatic speed limiter.....60
    - battery charge.....58
    - brake.....58, 60
    - critical warning message.....59
    - cruise control.....61
    - diesel glow plugs.....61
    - DSC active.....60
    - engine/transmission.....60
    - engine temperature.....59
    - external temperature.....61
    - forward alert.....62
    - gear shift warning lamp.....62
    - HDC.....62
    - headlamp high beam.....63
    - high beam assist.....62
    - hybrid vehicle battery fault.....59
    - indicators.....61
    - intelligent stop/start (green).....62
    - intelligent stop/start (white).....63

- lamp test.....58
- lane departure (green).....62
- lane departure (red).....59
- low fuel.....61
- low oil pressure.....59
- low range selected.....62
- parking brake.....59
- progress control system.....61
- rear fog lamps.....61
- seat belt.....59
- side lights.....62
- trailer direction indicators.....62
- tyre pressure monitoring system (TPMS).....61
- Warning messages.....54
  - hybrid vehicles.....118
- Washer jets.....270
- Washer reservoir
  - capacity.....332
- Washers.....69
  - fluid specification.....277
  - fluid top up.....277
  - headlamps.....71
- Water in fuel.....245
- Web browsing
  - InControl connection.....219
- Weights
  - gross vehicle weights.....334
  - roof load.....334
  - roof rack weight.....334
  - tow ball/hitch.....105
  - towing.....105
  - vehicle weights.....334
- Wheel changing
  - important information.....314
  - locking wheel nuts.....315
  - recommended process.....315
  - safety warnings.....312
  - spare wheel.....313
  - temporary spare wheel.....315
  - tilt sensor.....315
  - tool kit.....313
  - use of spare tyre.....314
- Wheel chocks use.....315
- Wheels and tyres
  - age degradation.....300
  - changing a tyre.....306
  - checking the pressures after a repair.....310
  - flat spots.....299
  - full size replacements.....305
  - Indian regulations.....303
  - pressures.....297
  - puncture repair.....307
  - puncture repair safety.....307
  - repair kit.....307
  - repair kit use.....308
  - repair procedure.....308
  - replacements.....299
  - snow chains.....302
  - temporary use spare.....306
  - TPMS.....304
  - TPMS warning lamp.....61
  - tyre care.....296
  - tyre speed ratings.....296
  - tyre wall markings.....295
  - ultra high performance tyres.....301
  - valves.....298
  - winter tyres.....300
- Wheel spin.....131
- Wi-Fi
  - InControl connection.....219
- Windows
  - anti-trap protection.....82
  - operation.....81
  - reset.....264
  - solar attenuating.....83
  - sunroof reset.....264
- Winter park position.....264
- Winter tyres.....300
- Wipers.....69
- Wipers and washers.....69
  - fluid level.....277
  - rain sensor.....70
  - speed-dependent mode.....70
  - winter park position.....71