

- Vehicle battery
 - battery monitoring system.....283
 - connecting jump leads.....280
 - effects of disconnection.....282
 - removing.....282
 - replacing.....282
 - warning symbols.....279
 - Vehicle battery care.....279
 - Vehicle cleaning
 - after driving off-road.....267
 - airbag covers.....270
 - alloy wheels.....268
 - engine compartment.....266
 - interior.....268–269
 - under body.....266
 - washer jets.....270
 - Vehicle data recording.....325
 - Vehicle loading tyre pressures.....305
 - Vehicle location
 - InControl secure.....219
 - Vehicle recovery
 - front towing eye.....319
 - off-road.....322
 - rear towing eye.....319
 - steering column lock.....9
 - towing on four wheels.....322, 324
 - transmission park release.....321
 - transporting the vehicle.....322
 - unlocking the steering column.....322
 - Vehicle storage.....252
 - Vehicle testing on rolling roads.....254
 - Video media player
 - controls.....196
 - dual view.....198
 - controls.....198
 - headphones.....199
 - full screen view.....197
 - headphones.....203
 - inhibited display.....197
 - rear media touch screen control.....200
 - rear media use.....202
 - VIN number.....327
 - Voice control.....205
 - navigation POI categories.....207
 - recognising your voice.....206
 - settings
 - command list.....207
 - operating guide.....207
 - preferences.....207
 - voicetags.....207
 - voice training.....207
 - training the system.....206
 - tutorial.....206
 - voicetags.....207
 - Voice guidance.....229
 - Volume
 - telephone.....213
- ## W
- Wade sensing
 - controls.....173
 - Wading depth
 - touch screen aid.....173
 - Warning lamps.....58, 61–62
 - ABS.....60
 - ACC follow mode.....61
 - adaptive front lighting system (AFS).....60
 - airbags.....48, 60
 - automatic speed limiter.....60
 - battery charge.....58
 - brake.....58, 60
 - critical warning message.....59
 - cruise control.....61
 - diesel glow plugs.....61
 - DSC active.....60
 - engine/transmission.....60
 - engine temperature.....59
 - external temperature.....61
 - forward alert.....62
 - gear shift warning lamp.....62
 - HDC.....62
 - headlamp high beam.....63
 - high beam assist.....62
 - hybrid vehicle battery fault.....59
 - indicators.....61
 - intelligent stop/start (green).....62
 - intelligent stop/start (white).....63

- lamp test.....58
- lane departure (green).....62
- lane departure (red).....59
- low fuel.....61
- low oil pressure.....59
- low range selected.....62
- parking brake.....59
- progress control system.....61
- rear fog lamps.....61
- seat belt.....59
- side lights.....62
- trailer direction indicators.....62
- tyre pressure monitoring system (TPMS).....61
- Warning messages.....54
 - hybrid vehicles.....118
- Washer jets.....270
- Washer reservoir
 - capacity.....332
- Washers.....69
 - fluid specification.....277
 - fluid top up.....277
 - headlamps.....71
- Water in fuel.....245
- Web browsing
 - InControl connection.....219
- Weights
 - gross vehicle weights.....334
 - roof load.....334
 - roof rack weight.....334
 - tow ball/hitch.....105
 - towing.....105
 - vehicle weights.....334
- Wheel changing
 - important information.....314
 - locking wheel nuts.....315
 - recommended process.....315
 - safety warnings.....312
 - spare wheel.....313
 - temporary spare wheel.....315
 - tilt sensor.....315
 - tool kit.....313
 - use of spare tyre.....314
- Wheel chocks use.....315
- Wheels and tyres
 - age degradation.....300
 - changing a tyre.....306
 - checking the pressures after a repair.....310
 - flat spots.....299
 - full size replacements.....305
 - Indian regulations.....303
 - pressures.....297
 - puncture repair.....307
 - puncture repair safety.....307
 - repair kit.....307
 - repair kit use.....308
 - repair procedure.....308
 - replacements.....299
 - snow chains.....302
 - temporary use spare.....306
 - TPMS.....304
 - TPMS warning lamp.....61
 - tyre care.....296
 - tyre speed ratings.....296
 - tyre wall markings.....295
 - ultra high performance tyres.....301
 - valves.....298
 - winter tyres.....300
- Wheel spin.....131
- Wi-Fi
 - InControl connection.....219
- Windows
 - anti-trap protection.....82
 - operation.....81
 - reset.....264
 - solar attenuating.....83
 - sunroof reset.....264
- Winter park position.....264
- Winter tyres.....300
- Wipers.....69
- Wipers and washers.....69
 - fluid level.....277
 - rain sensor.....70
 - speed-dependent mode.....70
 - winter park position.....71