
ELECTRIC SEATS



Do not adjust the seat while the vehicle is moving. Doing so could cause a loss of vehicle control and personal injury.

Note: *This diagram covers all electric seat controls. Not all of these controls apply to all seats.*

1. Cushion length.
2. Bolster inflate/deflate.
3. Lumbar support.
4. Seat upper seatback angle.
5. Head restraint height.
6. Seatback angle.
7. Seat height.
8. Forward and rearward position.