ELECTRIC SEATS



E176440

Do not adjust the seat while the vehicle is moving. Doing so could cause a loss of vehicle control and personal injury.

Note: This diagram covers all electric seat controls. Not all of these controls apply to all seats.

1. Cushion length.

- 2. Bolster inflate/deflate.
- 3. Lumbar support.
- 4. Seat upper seatback angle.
- 5. Head restraint height.
- 6. Seatback angle.
- 7. Seat height.
- 8. Forward and rearward position.