Courtesy delay.....65
Covers
refitting.....257
removal.....257
Critical warning messages.....59
Cruise control.....157
ACC driving hints.....161
ACC emergency braking.....164
ACC follow mode.....159
ACC gap change.....159
ACC radar detection beam issues...162
ACC set speed and follow mode override.....160
adaptive cruise control.....158
adaptive cruise control malfunction.....162
follow mode.....159
forward alert in ACC.....163
resume ACC follow mode.....161
resume ACC set speed.....161
using ACC.....158
warning lamp.....61
Curtain airbags.....47

D

DAB radio
ensembles.....186
settings.....185
DAB radio controls.....184
Data recording.....325
Daytime running lamps.....65
Declarations of conformity.....341
navigation system.....240
DEF.....243
Deselecting valet mode.....87
Destination entry.....228
postcode.....230
search area.....227
Detection beam issues.....162
Diesel
anti misfuel device active.....247
filler flap.....246
fuel.....242
glow plugs
warning lamp.....61
misfuel device passive.....247
sulphur content.....242
water in fuel.....245
Diesel engines.....245
Diesel particulate filter (DPF).....253
sulphur content.....242
Differential control.....132
Dimensions.....335
Direction indicators.....64
warning lamp.....61
Disability modifications
airbags.....50
Disabling the passenger air bag.....49
Displays.....270
Door mirrors.....72
blind spot monitor.....74
closing vehicle sensing.....75
sensors.....76
Door transceiver
assistance.....79
erase all programming.....79
programming.....78
programming a single button.....79
programming the garage door opener.....78
Double locking.....16
full alarm.....17
Downloading from the internet
InControl connection.....219
DPF.....253
Drive away locking.....9
Driver exit
deactivating intelligent stop/start....125
Driver monitor.....143
Driving
ACC automatic switch-off.....160
ACC driving hints.....161
ACC emergency braking.....164
ACC follow mode.....159
ACC forward alert.....163
ACC gap change.....159
ACC malfunction.....162