REAR MEDIA CONTROL FROM THE TOUCH SCREEN



E 161610

Press the Media menu button, or touch the Media menu soft key from the Touch screen **Home menu** and then select the **Rear media** soft key.

Note: When the main Rear media control screen is displayed on the Touch screen, the Rear media remote control will be locked out.

- 1. Information display.
- 2. Touch to select the left rear screen.

 Sync: After selecting a source (see items 2 and 4), touch Sync to synchronise both screens. Both screens will then display the selected source.

Note: If both screens are already synchronised, the **Sync** button will be greyed-out.

- 4. Touch to select the right rear screen.
- 5. Limo Mode: Touch to switch Limousine mode On and Off.