


REAR MEDIA CONTROL FROM THE TOUCH SCREEN



E161910

Press the Media menu button, or touch the Media menu soft key from the Touch screen **Home menu** and then select the **Rear media** soft key.

Note: When the main Rear media control screen is displayed on the Touch screen, the Rear media remote control will be locked out.

1. Information display.
2. Touch to select the left rear screen.

3. **Sync:** After selecting a source (see items 2 and 4), touch **Sync** to synchronise both screens. Both screens will then display the selected source.

Note: If both screens are already synchronised, the **Sync** button will be greyed-out.

4. Touch to select the right rear screen.
5. **Limo Mode:** Touch to switch Limousine mode **On** and **Off**.