

## CANCEL ROUTE GUIDANCE

To cancel Route guidance, proceed as follows:

1. Touch **Nav menu** on the navigation screen.
2. Touch the **Cancel guidance** soft key.

## QUICK POI SELECTION

1. Touch the map to display the extra options.
2. Touch the **Point of interest (POI)** soft key.
3. The screen shows 6 suggested categories; 5 of which can be selected as Quick POIs.
4. Select a Quick POI category, or touch **More...** to see further POIs. Touch **Ok** to confirm a selection.
5. The map with the POI icon(s) is displayed. Scroll the map to the POI icon, then touch **Set destination** to set and calculate the route.
6. Touch **GO** to start the journey.

**Note:** Selected POIs can be hidden, if required, by selecting **Nav menu**, followed by **Hide POI**.

**Note:** POI icons can only be displayed up to the 1 km zoom level.

## RESTORE SYSTEM DEFAULTS

From the **Nav menu**, select **Nav set-up**. If you have made any changes to the system's default settings, use this menu to restore the original settings.

## FAVOURITES

This enables you to manage destinations such as, place of work, home, favourite restaurant, etc.

From the **Favourite** sub-menu in **Stored locations**, you can save up to 400 stored favourites.

1. From the **Nav menu**, touch **More...**
2. Select **Stored locations**.
3. Touch **Favourite**.
4. To store a favourite, select **Add** from the sub-menu.
5. Select any destination entry method and confirm the desired location.

## FAVOURITES DETAILS

1. From the **Nav menu**, touch **More...**
2. Select **Stored locations**.
3. Select **Favourite**.
4. Select **Edit** or **Delete**.
5. Touch the selected favourite to display the details.
6. Select the chosen detail to edit. Details include **Attribute**, **Name**, **Phone number**, **Location**, and **Icon**.

## HOME

1. From the **Nav menu**, touch **More...**
2. Select **Stored locations**.
3. Touch **Home location**.
4. To store a home location, select **Add** from the sub-menu.
5. Select any destination entry method to set your home location. Touch **Ok** to confirm.
6. Touch **Ok** from the favourite summary; home location is now set.

## POSTCODE

**Note:** This facility is not available in all countries.