CANCEL ROUTE GUIDANCE

To cancel Route guidance, proceed as follows:

1. Touch **Nav menu** on the navigation screen.
2. Touch the **Cancel guidance** soft key.

QUICK POI SELECTION

1. Touch the map to display the extra options.
2. Touch the **Point of interest** (POI) soft key.
3. The screen shows 6 suggested categories; 5 of which can be selected as Quick POIs.
4. Select a Quick POI category, or touch **More...** to see further POIs. Touch **Ok** to confirm a selection.
5. The map with the POI icon(s) is displayed. Scroll the map to the POI icon, then touch **Set destination** to set and calculate the route.
6. Touch **GO** to start the journey.

*Note: Selected POIs can be hidden, if required, by selecting **Nav menu**, followed by **Hide POI**.*

Note: POI icons can only be displayed up to the 1 km zoom level.

RESTORE SYSTEM DEFAULTS

From the **Nav menu**, select **Nav set-up**. If you have made any changes to the system's default settings, use this menu to restore the original settings.

FAVOURITES

This enables you to manage destinations such as, place of work, home, favourite restaurant, etc.

From the **Favourite** sub-menu in **Stored locations**, you can save up to 400 stored favourites.

1. From the **Nav menu**, touch **More...**.
2. Select **Stored locations**.
3. Touch **Favourite**.
4. To store a favourite, select **Add** from the sub-menu.
5. Select any destination entry method and confirm the desired location.

FAVOURITES DETAILS

1. From the **Nav menu**, touch **More...**.
2. Select **Stored locations**.
3. Select **Favourite**.
4. Select **Edit** or **Delete**.
5. Touch the selected favourite to display the details.
6. Select the chosen detail to edit. Details include **Attribute**, **Name**, **Phone number**, **Location**, and **Icon.**

HOME

1. From the **Nav menu**, touch **More...**.
2. Select **Stored locations**.
3. Touch **Home location**.
4. To store a home location, select **Add** from the sub-menu.
5. Select any destination entry method to set your home location. Touch **Ok** to confirm.
6. Touch **Ok** from the favourite summary; home location is now set.

POSTCODE

Note: This facility is not available in all countries.