


SURROUND CAMERA SYSTEM



It remains the driver's responsibility to detect obstacles and estimate the vehicle's distance from them when manoeuvring the vehicle.



To switch on the Surround camera system, press the button on the Touch screen surround. Alternatively, select **Extra features** on the **Home menu**, then **Cameras**. See **86, TOUCH SCREEN HOME MENU**.



E174806

1. **Enlarge:** To enlarge a camera view, touch the image, then touch the **Enlarge** soft key. Any two images can be selected and enlarged, to view side-by-side, on the screen. When viewing two images, one of them can be selected to view as a full screen image. It can be zoomed into and panned around using the magnifier and arrow icons.
2. **Proximity View:** Touch to display a combination of two images from the front and passenger side cameras.
3. **Special Views:** Touch to display a selection of preset views. They are provided to assist with difficult manoeuvres and are:
 - **Kerb View:** Shows views in close proximity to each side of the vehicle.
 - **T Junction View:** Shows views to the left and right from the front camera.
 - **Trailer View:** Shows the default trailer view for the connected trailer.
 - **Birds-eye View:** Shows a 360° plan view from above, using all four cameras.
 - **Rear Junction:** Shows a very wide-angle view from the Rear camera.
4. **Tow Assist:** Touch to display the trailer guidance setup screen.

The four cameras that are used for the Surround camera system are located in the centre of the front grille, above the rear licence plate, and underneath each of the exterior door mirrors.

Note: The quality of the camera views may vary in different lighting conditions.

Note: Make sure that these areas are kept clean and free from obstructions, for example, stickers, debris, mud, snow, ice, etc. See **254, SENSORS AND CAMERAS**.

Camera shortcuts

The function of the Surround camera button on the Touch screen surround varies, depending on the selected gear and the vehicle's road speed, and gives the following options:

- When in a forward gear:
 - Press once to select the **T Junction View**.
- When in Neutral (**N**) or Park (**P**):
 - Press once to select the **Birds-eye View**.
- When in Reverse (**R**):
 - Press once to select the **Rear Junction View**.