ELECTRONIC TRACTION CONTROL (ETC)

The Electronic Traction Control (ETC) system operates in conjunction with Dynamic Stability Control (DSC) and is designed to assist if any of the wheels lose traction, causing wheel spin. See **126, DYNAMIC STABILITY CONTROL (DSC)**.

If a wheel loses traction, then ETC will operate the brake on that wheel and may also manipulate the engine output, until the wheel regains traction. The DSC amber warning lamp will flash to confirm that ETC is active. See **62, DYNAMIC STABILITY CONTROL (DSC) (AMBER)**.