
USING VOICE CONTROL



Note: The Voice control system has been designed to recognise a number of languages. However, it cannot be guaranteed that the system will be compatible with every accent group within those languages. Contact a Retailer/ Authorised Repairer about testing the Voice control system for compatibility with a particular accent group.

 Voice button: Press briefly to start a voice session. A pop-up menu will appear on the Touch screen. Press and hold to cancel a voice session.

Note: Briefly press the voice button during a voice session, to interrupt audible feedback. Wait for the tone to sound before giving the next command.

Voice control symbol: Indicates that a command is available. Wait for the symbol to appear and a tone to sound before using the command. Command list: Appears on the pop-up menu, providing feedback and available commands at each stage of the voice session. Say an available command.

Note: As the commands are listed before the system is ready to listen, it is important to wait for the voice symbol to appear alongside the relevant command, before using the command.

- **4.** When displayed, say **Cancel** to cancel the current voice session.
- **5.** When displayed, say **Help** to get assistance during a voice session.

Note: The currently selected user (**User 1** or **User 2**) is identified at the bottom of the command list.

Note: If a listed item is longer than the available space on the menu, ...> will appear. Use the seek controls on the steering wheel to view the entire entry. See 168, AUDIO/VIDEO CONTROLS.

VOICE TUTORIAL

To listen to the Voice tutorial, detailing the operation of the Voice control system:

- 1. Briefly press the steering wheel's Voice button to start a voice session.
- 2. Wait for a tone to sound, then say Voice tutorial.

Alternatively, the Voice tutorial can be selected using the Touch screen, as follows:

- Select the Setup icon from the Touch screen Home menu. See 86, TOUCH SCREEN HOME MENU.
- 2. Select Voice from the Setup menu.
- **3.** Select **Operating guide** from the **Voice settings** menu.
- 4. Select Voice tutorial.

Follow the instructions shown on the Touch screen.

The Voice tutorial can be cancelled at any time, by touching the Touch screen, or by pressing and holding the steering wheel's Voice button.

VOICE TRAINING

This is a feature designed to enable the system to better recognise the vocal characteristics of a user, once the training has been completed. To carry out Voice training:

- Select the Setup icon from the Touch screen Home menu. See 86, TOUCH SCREEN HOME MENU.
- 2. Select Voice from the Setup menu.
- **3.** Select **Voice training** from the **Voice settings** menu.
- **4.** Select **User 1** or **User 2**, to start the training.

Follow the Touch screen and the audible instructions.

The training session can be cancelled at any time, by touching the Touch screen, or by pressing and holding the steering wheel's Voice button.

VOICETAGS

Voicetags enable the user to personalise the Voice control system so that a single name can be used to access a navigation destination, phone number, or a radio channel.

To add a Voicetag:

- 1. Briefly press the Voice button to start a voice session.
- 2. Wait for the tone to sound and then say **Phone**, **Navigation**, or **Radio**.
- 3. Say Store voicetag.

Alternatively, Voicetags can be managed via the Touch screen, as follows:

- Select the Setup icon from the Touch screen Home menu. See 86, TOUCH SCREEN HOME MENU.
- 2. Select Voice from the Setup menu.
- 3. Select Voicetags from the Voice settings menu.
- Select the system which the Voicetag is to activate (Phone, Navigation, or Radio/DAB).

Follow the Touch screen and audible instructions.

VOICE SETTINGS

- Command list: Pressing the 'I' soft key next to any command will display alternative ways of saying the same command.
- Voicetags: View the categories. Select a category to manage the Voicetags for the chosen system. See 198, VOICETAGS.
- Operating guide: Select to view some brief Voice system instructions. Select Voice tutorial for more detailed Voice system instructions (cancel via the displayed pop-up, or by pressing and holding the Voice button).
- Preferences: Select to alter the following settings:
 - Voice profile: The Voice control system can be trained to have a greater recognition of a particular voice or accent. The default setting is All. To build a voice profile for either User 1 or User 2, it is necessary to complete a training program first.

To complete the training for the first time, select either **User 1** or **User 2** and follow the on-screen and audible instructions.

- Voice feedback: Select On/Off.
- Feedback volume: Adjust using the +/- buttons. It is not possible to reduce the volume to zero.
- Voice training: Select to access the Voice control system training program, designed to enable the system to better recognise the vocal characteristics of a user. Select User 1 or User 2 and follow the on-screen and audible instructions. See 198, VOICE TRAINING.

The training session can be cancelled, at any time, by touching the on-screen pop-up, or by pressing and holding the voice button on the steering wheel. See 197, USING VOICE CONTROL.

NAVIGATION POI VOICE COMMANDS

To request the display of Points Of Interest (POI) identifiers on the navigation display, say **Navigation** with one of the following POI categories:

- Petrol station/Petrol
- Parking/Car park
- Land Rover Retailer
- Hospital
- Golf course
- Tourist information
- Restaurant/I'm hungry
- · Shopping centre
- Hotel
- Motorway service
- Town centre

Note: The word **Navigation** must be followed immediately by a category. Icons will appear on the navigation display, indicating the locations of the selected POI. For further information about POIs, see **223**, **MY POI**.