## INTERIOR LIGHTS




- OFF position - permanently off.
- Central position - automatic operation:
  When a door is opened the lamps will illuminate for 15 seconds after the door is closed or until the starter switch is turned on.
  The tail-door of a station wagon will also activate the interior lamps.

  ***Note:*** *If a door remains open while the switch is in automatic position, the lamps will extinguish after approximately 8 minutes.*
- ON position - permanently on.