


FOLDING AND ERECTING THE REAR SEATS



SL1135



Always ensure that objects carried in the vehicle are secured properly.



Never allow passengers to travel in the load space under any circumstances.



Ensure that when the backrest(s) is raised, the locking mechanism is fully engaged. If the backrest(s) is not fully locked in place, red markers will be visible around the backrest levers.

The split fold rear seat can be folded completely to accommodate large loads, or partially to accommodate large loads and still retain seating for passengers.

To fold part or all of the seat:

1. Fully lower the head restraints.
2. Pull the strap on the required cushion(s), to raise to the vertical position.
3. Pull the seat backrest release lever(s), then lower the backrest(s) until locked into place.

To raise part or all of the seat:

4. Pull the strap(s) on the back of the seats vertically, to unlock the backrest.
5. Raise the backrest, ensuring the seat belt(s) are not trapped, until it clicks into position and the release lever is locked in position.
6. Push the seat cushion firmly into position.

To lower the armrest:

7. Pull the loop at the top of the centre seat.
8. Push the armrest down to the required position.

To stow the armrest, raise it and push it into the seatback until it clicks in place.

REAR HEAD RESTRAINTS




Adjust the head restraint so that the top of the head restraint is above the centre line of the head. An incorrectly adjusted head restraint increases the risk of death or serious injury in the event of a collision.




Do not drive or carry passengers with the head restraint removed from an occupied seat.



Always store a removed restraint securely.



SL1612



To adjust:

- Press the locking button on the collar.
- Raise or lower the head restraint until the top of the restraint is level with the top of the passenger's head.

To remove:

- Press the locking button on the collar.
- Lift the head restraint out of the seat.

To refit:

- Ensure the head restraint is facing the correct direction.
- Insert the stems of the restraint into the sockets on the seatback.
- Push the restraint downwards until at least the first click.