

## TIRE PRESSURES

### **⚠️ WARNING**

Never drive your vehicle if the tire pressures are incorrect. Under-inflation causes excessive flexing and uneven tire wear. This can lead to sudden tire failure. Over-inflation causes harsh ride, uneven tire wear and poor handling.

### **⚠️ WARNING**

Pressure checks should only be carried out when the tires are cold, and the vehicle has been stationary for more than three hours. A hot tire at or below recommended cold inflation pressure is dangerously under-inflated.

### **⚠️ WARNING**

Under-inflation also reduces fuel efficiency and tire tread life and may affect the vehicle's handling and stopping ability.

### **⚠️ WARNING**

If the vehicle has been parked in strong sunlight, or used in high ambient temperatures do not reduce the tire pressures. Move the vehicle into the shade and allow the tires to cool before rechecking the pressures.

Wheels	Tire size	Pressure - front psi / kPa	Pressure - rear psi / kPa
7J x 17*	225/65 R17 106V	35 / 240	30 / 210
8J x 18	235/60 R18 103/107V	35 / 240	30 / 210
8J x 19	235/55 R19 101/105V	36 / 250	32 / 220
8J x 20**	245/45 R20 99/103V	36 / 250	32 / 220
4.0J x 18	155/85 R18 temporary spare	59 / 410	