


FOLDING AND RAISING THE THIRD ROW SEATS

**⚠ WARNING**

To reduce the risk of neck injury in the event of a collision or sudden stop, the head restraint must always be raised when a third row seat is occupied.

- 1. To fold:** Press the head restraint release button, and fold the head restraint fully downwards.

- 2.** Pull up the release strap (located at rear of cushion) to release the seat. This may require moderate force. Fold the cushion fully forwards until it latches into position.
- 3.** Pull up the backrest lever and fold the backrest fully forwards, until it latches into position in the loadspace floor.
- 4. To raise:** Pull backrest lever to release the backrest, and raise to the upright position. Ensure it is fully latched into position.

Rear seats

5. Release the catch to raise cushion. Push into place, ensuring the cushion is latched to the backrest.
6. Raise the head restraint until it latches into position.