


FOLDING AND RAISING THE THIRD ROW SEATS



E134919

⚠ WARNING

To reduce the risk of neck injury in the event of a collision or sudden stop, the head restraint must always be raised when a third row seat is occupied.

⚠ WARNING

When raising the rear seats, make sure that seat belts are correctly routed in the seat belt guides and not trapped behind the seats.

- 1. To fold:** Press the head restraint release button, and fold the head restraint fully downwards.
- 2.** Pull up the release strap (located at rear of cushion), to release the seat. This may require moderate force. Fold the cushion fully forwards until it latches into position.
- 3.** Pull up the seat back release lever and fold the seat back fully forwards, until it latches into position in the loadspace floor.

Rear seats

4. **To raise:** Pull seat back release lever to release the seat back, and raise to the upright position. Make sure it is fully latched into position.
5. Release the catch, to raise the cushion. Push into place, making sure that the cushion is latched to the seat back.
6. Raise the head restraint until it latches into position.