


## FOLDING AND RAISING THE THIRD ROW SEATS



E134919



**The head restraint must always be raised when using the third row seats.**



**When raising the rear seats, make sure that the seat belts are correctly routed in to the seat belt guides and not trapped behind the seats.**

1. **To fold:** Press the head restraint release button, and fold the head restraint fully downwards.
2. Pull up the release strap (located at rear of cushion) to release the seat. This may require moderate force. Fold the cushion fully forwards until it latches into position.
3. Pull up the seatback release lever and fold the seatback fully forwards, until it latches into position in the loadspace floor.
4. **To raise:** Pull the seatback release lever to release the seatback, and raise to the upright position. Make sure it is fully latched into position.

## Rear seats

5. Release the catch, to raise the cushion.  
Push into place, making sure that the cushion is latched to the seatback.
6. Raise the head restraint until it latches into position.