

 When returning the seat from the access position, make sure nothing is trapped beneath the returning seat.



 Make sure that when the seatback and seat are returned to the pre-access position, the locking mechanisms are fully engaged. Physically test to make sure that the seat and seatback is secure before driving.

FOLDING AND RAISING THE THIRD ROW SEATS


 The head restraint must always be raised when using the third row seats.

 When raising the rear seats, make sure that seat belts are correctly routed and not trapped behind the seats.

 Beware of trapping fingers when raising and lowering the third row seat.



E163563






To raise a third row seat:

1. From inside the loadspace: On the seat to be raised, pull the strap on the rear of the seat, to lift the seat into the raised position.

Note: The seat is heavy, so care should be taken when raising the seat.

2. From inside the vehicle: Lift the head restraint, until it locks into the upright position.



E163564

To fold a third row seat:

1. From inside the loadspace: Pull the strap on the rear of the seat to be folded, to release the head restraint locking mechanism and then manually fold the head restraint forward.

Rear seats

2. To fold the seat: Pull the strap again to release the seat locking mechanism, and then fold the seat forwards into the stowed position.

Note: *The seat is heavy, so care should be taken when lowering the seat.*

Instructional video - Folding and raising the third row seats.



E166650