






Vehicle cleaning

-  Any staining should be cleaned within 24 hours of the event, otherwise it may become permanent.
-  Do not use any cleaning or stain removing products other than a mild soap and water.
-  Do not use any type of wax/wash product. Wax polish will become ingrained in the soft top roof material.
- Use a soft brush to remove dust and dirt (not the windows), then soak with a mild solution of soap and water.
- Wash off then rinse away all traces of soap with clean water.
- Make sure that the soft top roof is dry before removing or folding.

THE INTERIOR


 **When using cleaning products, make sure that you read the manufacturer's instructions. Some products contain substances that are harmful to health if used incorrectly and may also cause damage to interior surfaces.**

 **Do not polish the instrument panel. Polished surfaces are reflective, and may interfere with the drivers view.**

Clean plastic or cloth faced surfaces with warm water and non-detergent soap. Wipe clean with a soft cloth.

When cleaning the electrical equipment (instrument panel, clock, audio equipment etc) do not use cleaning fluids or sprays.

LEATHER UPHOLSTERY

 Only use cleaning products specifically designed for use on leather. Do not use chemical, alcohol, or abrasive materials, as they will cause rapid deterioration of the leather. The use of products which are not approved will invalidate your warranty.

If you are in any doubt as to which products to use, consult your Land Rover Dealer/Approved Repairer.

Leather should be cleaned and protected at least every 6 months.


Land Rover recommend the use of leather cleaning kit BAC500490. Use only in accordance with the instructions.


***Note:** Some materials/fabrics are prone to dye transfer, which can cause unsightly discolouration of lighter coloured leathers. Affected areas should be cleaned and re-protected as soon as possible.*

FABRIC UPHOLSTERY

Use only a diluted solution of an approved upholstery cleaner. It is advisable to test all cleaners on a concealed area before use.

SEAT BELTS

 **Do not allow any water, cleaning products, or fabric from cloths to enter the seat belt mechanism. Any substance which enters the mechanism may affect the performance of the seat belt in an impact.**

 **Care should be taken to avoid contamination of the seat belt webbing with polishes, oils, chemicals and particularly battery acid. Cleaning may safely be carried out using mild soap and water.**

Extend the seat belts fully, then use warm water and a non-detergent soap to clean. Allow the seat belts to dry naturally while fully extended.

Note: *While cleaning the seat belt, take the opportunity to examine the webbing for damage/wear. Any wear or damage should be reported to, and rectified by, a Dealer/Authorised repairer.*