CLEANING SWITCHES AND CONTROLS

- Use a soft, dry, lint-free cloth when cleaning switches or controls. Do not apply excessive pressure when doing so.
- Do not spray liquids directly onto the surface of switches and controls.
- Do not use chemical agents, solvents, or domestic cleaning products.
- When cleaning, do not allow sharp or abrasive objects to make contact with the components.

FABRIC UPHOLSTERY

Do not polish the Instrument panel. Polished surfaces are reflective, and may interfere with the driver's view.

Clean plastic or cloth-faced surfaces with warm water and non-detergent soap, and then wipe clean with a soft cloth.

LEATHER UPHOLSTERY

Only use cleaning products specifically designed for use on leather. Do not use chemical, alcohol, or abrasive materials, as they will cause rapid deterioration of the leather. The use of products which are not approved, will invalidate your warranty.

1

If you are in any doubt as to which products to use, consult your Retailer/Approved Repairer.

Leather should be cleaned and protected at least every 6 months.

To prevent ingrained dirt and staining, inspect the seat upholstery regularly, and clean every 1 to 2 months as follows:

- 1. Wipe off fine dust from the seat surfaces using a clean, damp, non-coloured cloth. Avoid over wetting the leather.
- 2. If this is not sufficient, use a cloth which has been dampened with warm, soapy water and then wrung out. Use only mild non-caustic soap.
- **3.** Use Land Rover leather cleaner for heavily soiled areas. Dry off and rub with a clean, soft cloth; changing surfaces regularly.

Use Land Rover leather cleaner several times a year to maintain the leather's suppleness and appearance. The cleaner will nourish and moisturise, and help to improve the surface's protective film against dust and substances.

- Dark clothing may stain leather seats, just like other upholstery products.
- Sharp objects, such as belts, zippers, rivets, etc., can leave permanent scratches and scratch marks on the leather surface.
- Unless spillages, such as tea, coffee, or ink, are washed away immediately, permanent staining may have to be accepted.

If a valet service is used, make sure the specialist concerned is aware of, and follows, these instructions precisely.

Note: Some materials/fabrics are prone to dye transfer, which can cause unsightly discolouration of lighter coloured leathers. Affected areas should be cleaned and re-protected as soon as possible.