



RANGE ROVER EVOQUE

OWNER'S HANDBOOK SUPPLEMENT

The following information should be read in conjunction with your Owner's Handbook. This supplement covers InControl.

Publication Part No. LSA 10 02 60 141

InControl

InControl uses Smartphone and in-vehicle mobile technology to connect your vehicle to breakdown, emergency and security services, as well as a number of convenience features. The Land Rover InControl Remote Smartphone App can be downloaded for Apple's iPhone from the Apple App Store, or for Android from Google Play.

If InControl has not been pre-registered by your Dealer, or you are not the first owner, you will need to visit

landroverincontrol.com/owner to create an account. Once your account has been created, follow the on-screen instructions to connect your account to your vehicle and to activate InControl.

Note: *Mobile connectivity cannot guarantee 100% coverage in all locations.*

Note: *It is your responsibility to remove the vehicle from your InControl account when ownership of the vehicle is transferred.*

Stolen vehicle tracking

InControl Secure provides a stolen vehicle tracking service. In the event that the vehicle has been tampered with or moved without consent, you will be contacted by the stolen vehicle tracking centre to confirm. Alternatively use the InControl Remote Smartphone App to contact the stolen vehicle tracking centre.

When the vehicle is being serviced/repaired or transported, then Service mode or Transport mode must be switched on/off via the Smartphone App or the Owner's site, to prevent a theft alert being triggered.

Note: The on/off status for Service mode and Transport mode should be updated every 10 hours, or earlier if required.

Note: *Further information is available on the Owner's section on **landrover.com***

Breakdown call



Located on the left side of the overhead console. See the Controls overview section of the Owner's Handbook for the exact location.

In the event of a breakdown, press and release the button cover to reveal the button. The button will be illuminated by a white LED. Press the button for 2 seconds to call and automatically supply your location and the vehicle's details to Land Rover Assistance. When a call is initiated the button will flash amber and will be constantly illuminated amber during an active call. Push the button cover back after use.

SOS emergency call



Located on the right side of the overhead console. See the Controls overview section of the Owner's Handbook for the exact location.

In the event that your personal safety or security is at risk, press and release the button cover to reveal the button. The button will be illuminated by a red LED. Press the button for 2 seconds to call and automatically supply your location and the vehicle's details to the emergency services. When the call is initiated the button will flash amber and will be constantly illuminated amber during an active call. Push the button cover back after use.

Note: *In the event that any of the vehicle's air bags are deployed, or a crash is detected, an SOS emergency call will be automatically triggered.*

Note: *If you are travelling in a different country, a call will still connect, however the vehicle's location and details may not be automatically sent.*