Head restraints

HEAD RESTRAINTS

Adjust, so that the top of the head restraint is the same height as the top of the seat occupant's head. Incorrect adjustment increases the risk of death or serious injury in the event of a collision.



Æ

 \wedge


Do not drive, or carry passengers with the head restraints removed from occupied seats. The absence of a correctly adjusted head restraint increases the risk of neck injury in the event of a collision.

Never adjust the head restraints while the vehicle is in motion.


Always store a removed head restraint securely.

ELECTRIC HEAD RESTRAINTS

MANUAL HEAD RESTRAINTS




- 1. To raise, pull the head restraint upwards. It will click and lock in position.
- 2. To lower, depress the locking button and push down on the restraint.



E150730

1. To adjust the height of the head restraint. See 17, ELECTRIC SEATS.

Note: It is not possible to remove electric head restraints.



- **1.** To raise, pull the head restraint upwards. It will click and lock in position.
- 2. To lower, depress the locking button and push down on the restraint.

HEAD RESTRAINT REMOVAL



Always store a removed head restraint securely.



Do not drive, or carry passengers with the head restraints removed from occupied seats. The absence of a correctly adjusted head restraint increases the risk of neck injury in the event of a collision or sudden stop.

Manual head restraints may be removed, if required (e.g. to fit larger child seats).

- 1. Raise the head restraint to its uppermost position and press the locking collar.
- 2. Lift the restraint out of the seatback

Make sure the head restraint is refitted before the seat is used by a passenger.

- 1. Make sure the restraint is facing the correct direction.
- 2. Insert the stems of the head restraint into the sockets on the seatback.
- **3.** Push the restraint downwards until at least the first click.

Note: See 36, RECOMMENDED CHILD SEATS, for details on correct child restraint installation