


Rear passenger controls

REAR SEAT CONTROLS

The rear seat control panels, located on the rear of the centre console, provides control of the audio system to the rear seat passengers.



E83103

1. 3.5 mm headphone socket
2. CD select
 - During CD play, press and release to select the next CD.
3. Mode control
 - Repeatedly press to scroll through FM, AM, CD and AUX modes.
4. Search up
 - During radio play, press to search up the frequency band for the next station with a good signal strength.

5. Volume increase
 - Press to increase headphone volume
6. Volume decrease
 - Press to decrease headphone volume
7. Search down
 - During radio play, press to search down the frequency band for the next station with a good signal strength.
 - During CD play, press and release to start the current track again. A second press will start the previous track.
 - During CD play, press and hold to search back through the track being played. Release button to stop search.

With the ignition on the rear seat controls can operate, regardless of whether the audio system is switched on or not. The play and selection features of the audio system will be available at the rear seat controls. However, the output can only be heard through the headphones.

If rear seat passengers are listening to the same source as the front seat passengers, only the volume can be adjusted at the rear seat controls.

For example, if a music CD is playing on the audio unit, rear seat passengers can listen to that music and adjust the volume to suit their requirement. No other functions will be available.

Rear passenger controls

If however, the audio unit is switched to another source, e.g. radio, all CD related rear seat controls become operable. If the audio source is subsequently switched back to CD, the rear seat controls will again be limited to volume control only.

The same logic applies to radio functions.

Adjustments can be made to other functions of the audio system.

For example, if a music CD is selected on the audio unit, radio can be selected and controlled using the rear seat controls. All radio related rear seat controls become operable.

HEADPHONES

Note: Only headphones compatible with a 3.5 mm jack plug socket can be used. To obtain optimum sound quality, use headphones with an impedance of 32 ohms.

Note: When the headphones are not connected, the rear seat controls remain operational. It is still possible to select CD, while the radio is playing on the audio unit. CD play will remain operational until the mode control is pressed again.

Note: Adjusting the volume on the audio unit, does not alter the headphone volume. The volume of each controller can be adjusted independently.