

# Traction control

---

## USING TRACTION CONTROL

### Electronic Traction Control (ETC)

ETC operates in conjunction with Dynamic Stability Control (DSC) and is designed to assist when one, or more, wheels have lost traction.

If a wheel loses traction, ETC will operate the brake on that wheel until it regains traction. The warning indicator will flash rapidly to inform the driver that ETC is operating.

### Warning indicator



If a fault is detected within the ETC system the warning indicator will flash continuously.

### Before driving off-road

Before venturing off-road it is absolutely essential that inexperienced drivers become fully familiar with the vehicle's controls. In particular, CommandShift, Hill Descent Control (HDC), and the Terrain Response system.

Basic information and off-road driving techniques can be found in the off-road driving handbook available on-line at

**<http://www.ownerinfo.landrover.com>**

Off-road driver training should be undertaken by anyone intending to drive off-road. Training is available at your nearest Land Rover Experience centre. More details can be found at **<http://www.landroverexperience.com>**