

# Wheels and tyres

---

## TYRE GLOSSARY

### lb/in<sup>2</sup> or PSI

Pounds per square inch, an imperial unit of measure for pressure.

### kPa

Kilo Pascal, a metric unit of measure for pressure.

### Cold tyre pressure

The air pressure in a tyre which has been standing in excess of three hours, or driven for less than one mile.

### Maximum inflation pressure

The maximum pressure to which the tyre should be inflated. This pressure is given on the tyre side wall in lbf/in<sup>2</sup> and kPa.

***Note:** This pressure is the maximum allowed by the tyre manufacturer. It is not the pressure recommended for use. See **TECHNICAL SPECIFICATIONS** (page 270).*

### Kerb weight

The weight of a standard vehicle, including a full tank of fuel, any optional equipment fitted, and with the correct coolant and oil levels.

### Gross vehicle weight

The maximum permissible weight of a vehicle with driver, passengers, load, luggage, equipment, and tow ball load.

### Accessory weight

The combined weight (in excess of those items replaced) of items available as factory installed equipment.

### Production options weight

The combined weight of options installed which weigh in excess of 1.4 kg (3 lb) more than the standard items that they replaced, and are not already considered in kerb or accessory weights. Items such as heavy duty brakes, high capacity battery, special trim etc.

### Vehicle capacity weight

The number of seats multiplied by 68 kg (150lb) plus the rated amount of load/luggage.

### Maximum loaded vehicle weight

The sum of kerb weight, accessory weight, vehicle capacity weight, and production options weight.

### Rim

The metal support for a tyre, or tyre and tube, upon which the tyre beads are seated.

### Bead

The inner edge of a tyre that is shaped to fit to the rim and form an air tight seal. The bead is constructed of steel wires which are wrapped, or reinforced, by the ply cords.