

DISCOVERY 4

OWNER'S HANDBOOK

Publication Part No. LRL 10 02 53 101

This handbook forms part of the Owner literature supplied with your new vehicle. Left hand drive and right hand drive conditions may be shown in the graphics and where information is specific to a particular country, it is indicated as such.

Please take the time to study the operating instructions with your vehicle as soon as you can.

Important

The information contained in this handbook covers all vehicle derivatives and optional equipment. Some of the options may not be fitted to your vehicle unless they formed part of the original vehicle specification. Therefore some parts of this handbook may not apply to your vehicle. Furthermore, due to printing cycles, it may include descriptions of options before they become generally available.

The options, hardware and software in your vehicle are from the available specifications for the market in which the vehicle was intended for sale. If your vehicle is to be used in another geographical area you may have to modify the vehicle specification to suit local conditions. Land Rover is not responsible for the cost of any modifications.

The information contained in this publication was correct when it went to print. Vehicle design changes may have been made after this handbook was printed. When this occurs a handbook supplement is added to the literature pack. Subsequent updates can be viewed on the Land Rover Internet site at; **www.ownerinfo.landrover.com**.

In the interest of development, the right is reserved to change specifications, design or equipment at any time without notice and without incurring any obligations. This publication, or part thereof, may not be reproduced nor translated without our approval. Errors and omissions excepted.

© Land Rover 2009

All rights reserved.

Published by Land Rover Technical Communications.

Contents

Introduction
SYMBOLS GLOSSARY 8
LABEL LOCATIONS 8
HEALTH AND SAFETY 9
DATA RECORDING 10
DISABILITY MODIFICATIONS 11
PARTS AND ACCESSORIES 11

Keys and remote controls
PRINCIPLE OF OPERATION 13
GENERAL INFORMATION ON RADIO FREQUENCIES 13
USING THE SMART KEY 14
UNLOCKING AND DISARMING THE VEHICLE. 15
LOCKING AND ARMING THE VEHICLE 16
CHANGING THE SMART KEY BATTERY 17
EMERGENCY KEY BLADE 17
GLOBAL OPENING AND CLOSING OF WINDOWS 18

Locks
LOCKING AND UNLOCKING 19
VALET MODE 20
USING THE EMERGENCY KEY BLADE 21
SMART KEY SYSTEM TRANSMITTERS 22
KEYLESS ENTRY 23
KEYLESS LOCKING 24
STEERING COLUMN LOCK 24

Engine immobiliser
PRINCIPLE OF OPERATION 25
CODED KEYS 25

Alarm
PRINCIPLE OF OPERATION 26
ARMING THE ALARM 26
SWITCHING OFF THE ALARM 27
TILT SENSOR 27

Facia
FACIA OVERVIEW 28

Driver information module
INFORMATION MESSAGES 30
TRIP COMPUTER 31
SERVICE INTERVAL INDICATOR 32
GEAR SELECTOR DISPLAY 32
VEHICLE INFORMATION AND SETTINGS MENU 33

Instruments
INSTRUMENT PANEL OVERVIEW 36
GAUGES 37
WARNING INDICATORS 38

Seats
SITTING IN THE CORRECT POSITION 40
MANUAL SEATS 41
ELECTRIC SEATS 42
DRIVER'S SEAT MEMORY FUNCTION 44
HEAD RESTRAINTS 45
REAR SEATS 46
HEATED SEATS 52

Seat belts
GENERAL INFORMATION 53
SEAT BELT REMINDER 55
FASTENING THE SEAT BELTS 56
SEAT BELT HEIGHT ADJUSTMENT 56
USING SEAT BELTS DURING PREGNANCY 57

Supplementary restraints system
PRINCIPLE OF OPERATION 58
SIDE AIRBAGS 61
CURTAIN AIRBAGS 61
DISABLING THE PASSENGER AIRBAG 62
AIRBAG WARNING LAMP 64
AIRBAG SERVICE INFORMATION 65

Child safety
CHILD SEATS 66
CHILD SEAT POSITIONING 68
ISOFIX ANCHOR POINTS 70
BOOSTER CUSHIONS 72
CHILD SAFETY LOCKS 72

Contents

Steering wheel

ADJUSTING THE STEERING COLUMN 73
HEATED STEERING WHEEL..... 74
AUDIO CONTROL 75
VOICE CONTROL 75
CRUISE CONTROL..... 75
HORN 75

Lighting

GENERAL INFORMATION 76
LIGHTING CONTROL 77
FRONT FOG LAMPS..... 79
REAR FOG LAMPS..... 79
HAZARD WARNING FLASHERS..... 79
HEADLAMPS - DRIVING ABROAD..... 80
ADAPTIVE FRONT LIGHTING SYSTEM..... 80
DIRECTION INDICATORS 82
INTERIOR LAMPS 82
REMOVING A HEADLAMP 83
REMOVING A REAR LAMP 85
CHANGING A BULB 85
HEADLAMP UNIT BULBS 86
FRONT FOG LAMP BULB 90
SIDE REPEATER LAMP BULB..... 91
REAR LAMP BULBS 92
INTERIOR LAMP BULBS 93
BULB SPECIFICATION CHART..... 94

Wipers and washers

WINDSCREEN WIPERS 95
RAIN SENSOR 96
WINDSCREEN WASHERS..... 97
REAR WINDOW WIPER AND WASHERS..... 97
HEADLAMP POWER WASH..... 98
ADJUSTING THE WINDSCREEN WASHER JETS 98
CHECKING THE WIPER BLADES 99
CHANGING THE WIPER BLADES..... 99

Windows and mirrors

ELECTRIC WINDOWS..... 101
EXTERIOR MIRRORS 102
INTERIOR MIRROR 104

Climate control

AIR VENTS 105
AUTOMATIC CLIMATE CONTROL 107
HEATED SCREENS AND MIRRORS..... 110
REAR PASSENGER CLIMATE CONTROLS..... 111
AUXILIARY HEATER..... 111
TIMED CLIMATE CONTROL 112
ELECTRIC SUNROOF..... 115

Convenience features

SUN VISORS..... 117
SUN BLINDS 117
INSTRUMENT LIGHTING DIMMER 117
CIGAR LIGHTER..... 118
ASHTRAY..... 118
AUXILIARY POWER SOCKETS 119
CUP HOLDERS..... 120
CENTRE CONSOLE..... 121
COOL BOX..... 122
STORAGE COMPARTMENTS..... 123

Homelink

HOMELINK® TRANSMITTER..... 124

Starting the engine

GENERAL INFORMATION..... 129
SWITCHING ON THE IGNITION..... 129
KEYLESS STARTING..... 130
IF THE ENGINE FAILS TO START 130
KEYLESS START BACKUP 131
STOPPING THE ENGINE..... 131

Transmission

MANUAL TRANSMISSION 132
AUTOMATIC TRANSMISSION..... 132
CommandShift™ GEAR SELECTION..... 134
ELECTRONICALLY SELECTED AUTOMATIC MODES..... 135
TRANSFER GEARBOX 137

Brakes

PRINCIPLE OF OPERATION 140
HINTS ON DRIVING WITH ABS..... 142
ELECTRIC PARKING BRAKE (EPB) 143

Contents

Camera systems
REAR VIEW CAMERA SYSTEM 147
SURROUND CAMERA SYSTEM 148

Parking aid
PRINCIPLE OF OPERATION 152
USING THE PARKING AID 152

Driving hints
GENERAL DRIVING POINTS 154
RUNNING-IN 155
ENGINE RELATED PROBLEMS 156
ECONOMICAL DRIVING 156
DIESEL PARTICULATE FILTER (DPF) 157

Cruise control
PRINCIPLE OF OPERATION 158
USING CRUISE CONTROL 158

Stability control
PRINCIPLE OF OPERATION 160
USING STABILITY CONTROL 160
ROLL STABILITY CONTROL (RSC) 161
TRAILER STABILITY ASSIST (TSA) 161

Traction control
PRINCIPLE OF OPERATION 162
SAND LAUNCH CONTROL 162
ROCK CRAWL PRECHARGE 162

Hill descent control (HDC)
PRINCIPLE OF OPERATION 163
USING HDC 163

Terrain response
PRINCIPLE OF OPERATION 166
USING TERRAIN RESPONSE 166

Air suspension
PRINCIPLE OF OPERATION 171
ADJUSTING THE SUSPENSION 172
REMOTE OPERATION 178

Fuel and refuelling
SAFETY PRECAUTIONS 179
FUEL SPECIFICATION 179
FUEL FOR PETROL ENGINES 180
ALTERNATIVE FUELS FOR PETROL ENGINES 180
FUEL FOR DIESEL ENGINES 181
FUEL FILLER 182
REFUELLING 183
DIESEL MISFUEL PROTECTOR 183
RUNNING OUT OF FUEL 184
DIESEL WATER IN FUEL SENSOR 185
FUEL CUT-OFF 185
CATALYTIC CONVERTER 185
FUEL CONSUMPTION 186

Load carrying
GENERAL INFORMATION 187
LUGGAGE ANCHOR POINTS 187
REAR LOADSPACE HATCHES 187
LUGGAGE COVERS 188

Towing
TOWING A TRAILER 190
LEVELLING 194
ESSENTIAL TOWING CHECKS 195
GEAR CHANGING 195
RECOMMENDED TOWING WEIGHTS 196
DETACHABLE TOW BALL 197
TOW BALL STOWAGE 199

Vehicle care
CLEANING THE EXTERIOR 200
CLEANING THE ALLOY WHEELS 201
CLEANING THE INTERIOR 201
REPAIRING MINOR PAINT DAMAGE 203

Maintenance
GENERAL INFORMATION 204
SAFETY IN THE GARAGE 205
OPENING AND CLOSING THE BONNET 206
ENGINE COMPARTMENT OVERVIEW 207
UNDER BONNET COVERS 209
ENGINE OIL 209
ENGINE OIL CHECK (2.7L DIESEL AND V6 PETROL) 210
ENGINE OIL CHECK (3.0L DIESEL) 211

Contents

ENGINE OIL CHECK (V8 PETROL) 213
ENGINE COOLANT CHECK 215
BRAKE FLUID CHECK 216
POWER STEERING FLUID CHECK 218
WASHER FLUID CHECK 219
TECHNICAL SPECIFICATIONS 220

Vehicle battery

BATTERY WARNING SYMBOLS 222
BATTERY CARE 222
USING BOOSTER CABLES 223
CHARGING THE VEHICLE BATTERY 225
CHANGING THE VEHICLE BATTERY 226
REFITTING THE VEHICLE BATTERY 227

Wheels and tyres

GENERAL INFORMATION 228
TOOL KIT 229
CHANGING A ROAD WHEEL 230
TYRE CARE 243
USING WINTER TYRES 248
APPROVED WINTER TYRES 249
USING SNOW CHAINS 249
TYRE PRESSURE MONITORING SYSTEM 250
TYRE GLOSSARY 254
TECHNICAL SPECIFICATIONS 255

Fuses

FUSE BOX LOCATIONS 256
CHANGING A FUSE 257
FUSE SPECIFICATION CHART 258

Status after a collision

DRIVING AFTER A COLLISION 263
INSPECTING SAFETY SYSTEM COMPONENTS 264

Vehicle recovery

TOWING POINTS 265
LASHING POINTS 267
TRANSPORTING THE VEHICLE 267
TOWING THE VEHICLE ON FOUR WHEELS 268

Vehicle identification

VEHICLE IDENTIFICATION NUMBER (VIN) 269
VEHICLE IDENTIFICATION PLATE 269
VEHICLE BUILD DATE PLATE 269
ENGINE NUMBER 269

Technical specifications

TECHNICAL SPECIFICATIONS 270

Type approvals

TYPE APPROVALS 276

Audio system overview

STANDARD AUDIO SYSTEM 286
TOUCH SCREEN AUDIO SYSTEM 287
TOUCH SCREEN CARE 288
SWITCHING THE SYSTEM ON 288
TURNING OFF THE TOUCH SCREEN 288

Audio system settings (touch screen)

PERSONALISING THE SYSTEM SETTINGS 289
SYSTEM SETTINGS 289
SCREEN SETTINGS 290
VEHICLE SETTINGS 291
VOICE SETTINGS 292

Audio level settings (touch screen)

VOLUME ADJUSTMENT 293
TONE ADJUSTMENT 294

Radio (standard)

RADIO RECEPTION 295
RADIO CONTROLS 296
VOLUME ADJUSTMENT 297
TONE ADJUSTMENT 297
RADIO OPERATION 297
RADIO DATA SYSTEM (RDS) 299
TRAFFIC INFORMATION 299
NEWS INFORMATION 300
TIME AND DATE SETTINGS 301

Contents

Radio (touch screen)
RADIO RECEPTION 302
RADIO CONTROLS 303
RADIO OPERATION 304
RADIO DATA SYSTEM (RDS) 305
TRAFFIC INFORMATION 306
NEWS INFORMATION 307
PRIORITY PROGRAMME TYPE (PTY) 307

Digital Audio Broadcasting (DAB)
GENERAL INFORMATION 308
AUDIO CONTROLS 310
USING DAB 311
CHANNEL AUTOMATIC TUNING 311
DISPLAY OPTIONS 312
PRESET CHANNELS 313
CHANNEL OPTIONS 314
SETTINGS 316

Compact disc player (standard)
COMPACT DISC COMPATIBILITY 319
PLAYING A COMPACT DISC 320
TRACK SELECTION 320
MP3 FILE PLAYBACK 321

Compact disc player (touch screen)
COMPACT DISC COMPATIBILITY 322
LOADING COMPACT DISCS 323
TRACK SELECTION 324
COMPACT DISC PAUSE 324
COMPACT DISC PLAY OPTIONS 325

Rear passenger controls
REAR SEAT CONTROLS 326
HEADPHONES 327

Portable audio interface
PORTABLE AUDIO INTERFACE 328
OPERATING A PORTABLE DEVICE 330
SEARCHING A PORTABLE DEVICE 331

Auxiliary input (AUX IN) socket
AUXILIARY INPUT (AUX IN) SOCKET 332

Voice control
USING VOICE CONTROL 334
DISPLAY COMMANDS 336
NOTEPAD COMMANDS 336

Telephone (standard)
GENERAL INFORMATION 337
MOBILE PHONE COMPATIBILITY 338
TELEPHONE CONTROLS 338
BLUETOOTH SETUP 339
SELECTING PHONE MODE 340
DIALLING 340
ANSWERING/REJECTING CALLS 340

Telephone (touch screen)
GENERAL INFORMATION 341
TELEPHONE CONTROLS 343
PHONE INFORMATION DISPLAY 344
BLUETOOTH SETUP 345
SELECTING PHONE MODE 346
DIALLING 346
ANSWERING/REJECTING CALLS 346
PHONEBOOK 347
SCRATCHPAD 348
CALL REGISTER 349
TELEPHONE VOICE CONTROL 350
DIALLING A PHONE NUMBER USING VOICE RECOGNITION 351
STORING A TELEPHONE NAME/ NUMBER WITH VOICE RECOGNITION 352
USING THE VOICE RECOGNITION PHONE DIRECTORY 353

Filling station information
FUEL FILLER FLAP 355
REFUELLING 355
TYRE PRESSURES 356
ENGINE OIL SPECIFICATION 356
ENGINE COOLANT SPECIFICATION 356