



# **DISCOVERY 4**

## **OWNER'S HANDBOOK**

**Publication Part No. LRL 10 02 53 101**

This handbook forms part of the Owner literature supplied with your new vehicle. Left hand drive and right hand drive conditions may be shown in the graphics and where information is specific to a particular country, it is indicated as such.

Please take the time to study the operating instructions with your vehicle as soon as you can.

### **Important**

*The information contained in this handbook covers all vehicle derivatives and optional equipment. Some of the options may not be fitted to your vehicle unless they formed part of the original vehicle specification. Therefore some parts of this handbook may not apply to your vehicle. Furthermore, due to printing cycles, it may include descriptions of options before they become generally available.*

*The options, hardware and software in your vehicle are from the available specifications for the market in which the vehicle was intended for sale. If your vehicle is to be used in another geographical area you may have to modify the vehicle specification to suit local conditions. Land Rover is not responsible for the cost of any modifications.*

The information contained in this publication was correct when it went to print. Vehicle design changes may have been made after this handbook was printed. When this occurs a handbook supplement is added to the literature pack. Subsequent updates can be viewed on the Land Rover Internet site at: **[www.ownerinfo.landrover.com](http://www.ownerinfo.landrover.com)**.

In the interest of development, the right is reserved to change specifications, design or equipment at any time without notice and without incurring any obligations. This publication, or part thereof, may not be reproduced nor translated without our approval. Errors and omissions excepted.

© Land Rover 2009

All rights reserved.

Published by Land Rover Technical Communications.

# Contents

---

## Introduction

SYMBOLS GLOSSARY .....	8
LABEL LOCATIONS .....	8
HEALTH AND SAFETY .....	9
DATA RECORDING .....	10
DISABILITY MODIFICATIONS .....	11
PARTS AND ACCESSORIES .....	11

## Keys and remote controls

PRINCIPLE OF OPERATION .....	13
GENERAL INFORMATION ON RADIO FREQUENCIES .....	13
USING THE SMART KEY .....	14
UNLOCKING AND DISARMING THE VEHICLE .....	15
LOCKING AND ARMING THE VEHICLE .....	16
CHANGING THE SMART KEY BATTERY .....	17
EMERGENCY KEY BLADE .....	17
GLOBAL OPENING AND CLOSING OF WINDOWS .....	18

## Locks

LOCKING AND UNLOCKING .....	19
VALET MODE .....	20
USING THE EMERGENCY KEY BLADE .....	21
SMART KEY SYSTEM TRANSMITTERS .....	22
KEYLESS ENTRY .....	23
KEYLESS LOCKING .....	24
STEERING COLUMN LOCK .....	24

## Engine immobiliser

PRINCIPLE OF OPERATION .....	25
CODED KEYS .....	25

## Alarm

PRINCIPLE OF OPERATION .....	26
ARMING THE ALARM .....	26
SWITCHING OFF THE ALARM .....	27
TILT SENSOR .....	27

## Facia

FACIA OVERVIEW .....	28
----------------------	----

## Driver information module

INFORMATION MESSAGES .....	30
TRIP COMPUTER .....	31
SERVICE INTERVAL INDICATOR .....	32
GEAR SELECTOR DISPLAY .....	32
VEHICLE INFORMATION AND SETTINGS MENU .....	33

## Instruments

INSTRUMENT PANEL OVERVIEW .....	36
GAUGES .....	37
WARNING INDICATORS .....	38

## Seats

SITTING IN THE CORRECT POSITION .....	40
MANUAL SEATS .....	41
ELECTRIC SEATS .....	42
DRIVER'S SEAT MEMORY FUNCTION .....	44
HEAD RESTRAINTS .....	45
REAR SEATS .....	46
HEATED SEATS .....	52

## Seat belts

GENERAL INFORMATION .....	53
SEAT BELT REMINDER .....	55
FASTENING THE SEAT BELTS .....	56
SEAT BELT HEIGHT ADJUSTMENT .....	56
USING SEAT BELTS DURING PREGNANCY ...	57

## Supplementary restraints system

PRINCIPLE OF OPERATION .....	58
SIDE AIRBAGS .....	61
CURTAIN AIRBAGS .....	61
DISABLING THE PASSENGER AIRBAG .....	62
AIRBAG WARNING LAMP .....	64
AIRBAG SERVICE INFORMATION .....	65

## Child safety

CHILD SEATS .....	66
CHILD SEAT POSITIONING .....	68
ISOFIX ANCHOR POINTS .....	70
BOOSTER CUSHIONS .....	72
CHILD SAFETY LOCKS .....	72

# Contents

---

## Steering wheel

ADJUSTING THE STEERING COLUMN .....	73
HEATED STEERING WHEEL.....	74
AUDIO CONTROL .....	75
VOICE CONTROL .....	75
CRUISE CONTROL.....	75
HORN .....	75

## Lighting

GENERAL INFORMATION .....	76
LIGHTING CONTROL .....	77
FRONT FOG LAMPS.....	79
REAR FOG LAMPS.....	79
HAZARD WARNING FLASHERS.....	79
HEADLAMPS - DRIVING ABROAD.....	80
ADAPTIVE FRONT LIGHTING SYSTEM.....	80
DIRECTION INDICATORS .....	82
INTERIOR LAMPS .....	82
REMOVING A HEADLAMP .....	83
REMOVING A REAR LAMP .....	85
CHANGING A BULB .....	85
HEADLAMP UNIT BULBS .....	86
FRONT FOG LAMP BULB .....	90
SIDE REPEATER LAMP BULB.....	91
REAR LAMP BULBS .....	92
INTERIOR LAMP BULBS .....	93
BULB SPECIFICATION CHART .....	94

## Wipers and washers

WINDSCREEN WIPERS .....	95
RAIN SENSOR .....	96
WINDSCREEN WASHERS.....	97
REAR WINDOW WIPER AND WASHERS.....	97
HEADLAMP POWER WASH.....	98
ADJUSTING THE WINDSCREEN WASHER JETS .....	98
CHECKING THE WIPER BLADES .....	99
CHANGING THE WIPER BLADES.....	99

## Windows and mirrors

ELECTRIC WINDOWS.....	101
EXTERIOR MIRRORS .....	102
INTERIOR MIRROR .....	104

## Climate control

AIR VENTS .....	105
AUTOMATIC CLIMATE CONTROL .....	107
HEATED SCREENS AND MIRRORS.....	110
REAR PASSENGER CLIMATE CONTROLS.....	111
AUXILIARY HEATER.....	111
TIMED CLIMATE CONTROL .....	112
ELECTRIC SUNROOF.....	115

## Convenience features

SUN VISORS .....	117
SUN BLINDS .....	117
INSTRUMENT LIGHTING DIMMER .....	117
CIGAR LIGHTER.....	118
ASHTRAY .....	118
AUXILIARY POWER SOCKETS .....	119
CUP HOLDERS.....	120
CENTRE CONSOLE.....	121
COOL BOX.....	122
STORAGE COMPARTMENTS.....	123

## Homelink

HOMELINK® TRANSMITTER.....	124
----------------------------	-----

## Starting the engine

GENERAL INFORMATION.....	129
SWITCHING ON THE IGNITION .....	129
KEYLESS STARTING .....	130
IF THE ENGINE FAILS TO START .....	130
KEYLESS START BACKUP .....	131
STOPPING THE ENGINE.....	131

## Transmission

MANUAL TRANSMISSION .....	132
AUTOMATIC TRANSMISSION .....	132
CommandShift™ GEAR SELECTION.....	134
ELECTRONICALLY SELECTED AUTOMATIC MODES.....	135
TRANSFER GEARBOX .....	137

## Brakes

PRINCIPLE OF OPERATION .....	140
HINTS ON DRIVING WITH ABS.....	142
ELECTRIC PARKING BRAKE (EPB) .....	143

# Contents

---

## Camera systems

REAR VIEW CAMERA SYSTEM.....	147
SURROUND CAMERA SYSTEM.....	148

## Parking aid

PRINCIPLE OF OPERATION.....	152
USING THE PARKING AID.....	152

## Driving hints

GENERAL DRIVING POINTS.....	154
RUNNING-IN.....	155
ENGINE RELATED PROBLEMS.....	156
ECONOMICAL DRIVING.....	156
DIESEL PARTICULATE FILTER (DPF).....	157

## Cruise control

PRINCIPLE OF OPERATION.....	158
USING CRUISE CONTROL.....	158

## Stability control

PRINCIPLE OF OPERATION.....	160
USING STABILITY CONTROL.....	160
ROLL STABILITY CONTROL (RSC).....	161
TRAILER STABILITY ASSIST (TSA).....	161

## Traction control

PRINCIPLE OF OPERATION.....	162
SAND LAUNCH CONTROL.....	162
ROCK CRAWL PRECHARGE.....	162

## Hill descent control (HDC)

PRINCIPLE OF OPERATION.....	163
USING HDC.....	163

## Terrain response

PRINCIPLE OF OPERATION.....	166
USING TERRAIN RESPONSE.....	166

## Air suspension

PRINCIPLE OF OPERATION.....	171
ADJUSTING THE SUSPENSION.....	172
REMOTE OPERATION.....	178

## Fuel and refuelling

SAFETY PRECAUTIONS.....	179
FUEL SPECIFICATION.....	179
FUEL FOR PETROL ENGINES.....	180
ALTERNATIVE FUELS FOR PETROL ENGINES.....	180
FUEL FOR DIESEL ENGINES.....	181
FUEL FILLER.....	182
REFUELLING.....	183
DIESEL MISFUEL PROTECTOR.....	183
RUNNING OUT OF FUEL.....	184
DIESEL WATER IN FUEL SENSOR.....	185
FUEL CUT-OFF.....	185
CATALYTIC CONVERTER.....	185
FUEL CONSUMPTION.....	186

## Load carrying

GENERAL INFORMATION.....	187
LUGGAGE ANCHOR POINTS.....	187
REAR LOADSPACE HATCHES.....	187
LUGGAGE COVERS.....	188

## Towing

TOWING A TRAILER.....	190
LEVELLING.....	194
ESSENTIAL TOWING CHECKS.....	195
GEAR CHANGING.....	195
RECOMMENDED TOWING WEIGHTS.....	196
DETACHABLE TOW BALL.....	197
TOW BALL STOWAGE.....	199

## Vehicle care

CLEANING THE EXTERIOR.....	200
CLEANING THE ALLOY WHEELS.....	201
CLEANING THE INTERIOR.....	201
REPAIRING MINOR PAINT DAMAGE.....	203

## Maintenance

GENERAL INFORMATION.....	204
SAFETY IN THE GARAGE.....	205
OPENING AND CLOSING THE BONNET.....	206
ENGINE COMPARTMENT OVERVIEW.....	207
UNDER BONNET COVERS.....	209
ENGINE OIL.....	209
ENGINE OIL CHECK (2.7L DIESEL AND V6 PETROL).....	210
ENGINE OIL CHECK (3.0L DIESEL).....	211

# Contents

---

ENGINE OIL CHECK (V8 PETROL) .....	213
ENGINE COOLANT CHECK .....	215
BRAKE FLUID CHECK .....	216
POWER STEERING FLUID CHECK .....	218
WASHER FLUID CHECK .....	219
TECHNICAL SPECIFICATIONS .....	220

## Vehicle battery

BATTERY WARNING SYMBOLS .....	222
BATTERY CARE .....	222
USING BOOSTER CABLES .....	223
CHARGING THE VEHICLE BATTERY .....	225
CHANGING THE VEHICLE BATTERY .....	226
REFITTING THE VEHICLE BATTERY .....	227

## Wheels and tyres

GENERAL INFORMATION .....	228
TOOL KIT .....	229
CHANGING A ROAD WHEEL .....	230
TYRE CARE .....	243
USING WINTER TYRES .....	248
APPROVED WINTER TYRES .....	249
USING SNOW CHAINS .....	249
TYRE PRESSURE MONITORING SYSTEM .....	250
TYRE GLOSSARY .....	254
TECHNICAL SPECIFICATIONS .....	255

## Fuses

FUSE BOX LOCATIONS .....	256
CHANGING A FUSE .....	257
FUSE SPECIFICATION CHART .....	258

## Status after a collision

DRIVING AFTER A COLLISION .....	263
INSPECTING SAFETY SYSTEM COMPONENTS .....	264

## Vehicle recovery

TOWING POINTS .....	265
LASHING POINTS .....	267
TRANSPORTING THE VEHICLE .....	267
TOWING THE VEHICLE ON FOUR WHEELS ..	268

## Vehicle identification

VEHICLE IDENTIFICATION NUMBER (VIN) ...	269
VEHICLE IDENTIFICATION PLATE .....	269
VEHICLE BUILD DATE PLATE .....	269
ENGINE NUMBER .....	269

## Technical specifications

TECHNICAL SPECIFICATIONS .....	270
--------------------------------	-----

## Type approvals

TYPE APPROVALS .....	276
----------------------	-----

## Audio system overview

STANDARD AUDIO SYSTEM .....	286
TOUCH SCREEN AUDIO SYSTEM .....	287
TOUCH SCREEN CARE .....	288
SWITCHING THE SYSTEM ON .....	288
TURNING OFF THE TOUCH SCREEN .....	288

## Audio system settings (touch screen)

PERSONALISING THE SYSTEM SETTINGS ...	289
SYSTEM SETTINGS .....	289
SCREEN SETTINGS .....	290
VEHICLE SETTINGS .....	291
VOICE SETTINGS .....	292

## Audio level settings (touch screen)

VOLUME ADJUSTMENT .....	293
TONE ADJUSTMENT .....	294

## Radio (standard)

RADIO RECEPTION .....	295
RADIO CONTROLS .....	296
VOLUME ADJUSTMENT .....	297
TONE ADJUSTMENT .....	297
RADIO OPERATION .....	297
RADIO DATA SYSTEM (RDS) .....	299
TRAFFIC INFORMATION .....	299
NEWS INFORMATION .....	300
TIME AND DATE SETTINGS .....	301

# Contents

---

## Radio (touch screen)

RADIO RECEPTION .....	302
RADIO CONTROLS .....	303
RADIO OPERATION .....	304
RADIO DATA SYSTEM (RDS) .....	305
TRAFFIC INFORMATION .....	306
NEWS INFORMATION .....	307
PRIORITY PROGRAMME TYPE (PTY) .....	307

## Digital Audio Broadcasting (DAB)

GENERAL INFORMATION .....	308
AUDIO CONTROLS .....	310
USING DAB .....	311
CHANNEL AUTOMATIC TUNING .....	311
DISPLAY OPTIONS .....	312
PRESET CHANNELS .....	313
CHANNEL OPTIONS .....	314
SETTINGS .....	316

## Compact disc player (standard)

COMPACT DISC COMPATIBILITY .....	319
PLAYING A COMPACT DISC .....	320
TRACK SELECTION .....	320
MP3 FILE PLAYBACK .....	321

## Compact disc player (touch screen)

COMPACT DISC COMPATIBILITY .....	322
LOADING COMPACT DISCS .....	323
TRACK SELECTION .....	324
COMPACT DISC PAUSE .....	324
COMPACT DISC PLAY OPTIONS .....	325

## Rear passenger controls

REAR SEAT CONTROLS .....	326
HEADPHONES .....	327

## Portable audio interface

PORTABLE AUDIO INTERFACE .....	328
OPERATING A PORTABLE DEVICE .....	330
SEARCHING A PORTABLE DEVICE .....	331

## Auxiliary input (AUX IN) socket

AUXILIARY INPUT (AUX IN) SOCKET .....	332
---------------------------------------	-----

## Voice control

USING VOICE CONTROL .....	334
DISPLAY COMMANDS .....	336
NOTEPAD COMMANDS .....	336

## Telephone (standard)

GENERAL INFORMATION .....	337
MOBILE PHONE COMPATIBILITY .....	338
TELEPHONE CONTROLS .....	338
BLUETOOTH SETUP .....	339
SELECTING PHONE MODE .....	340
DIALLING .....	340
ANSWERING/REJECTING CALLS .....	340

## Telephone (touch screen)

GENERAL INFORMATION .....	341
TELEPHONE CONTROLS .....	343
PHONE INFORMATION DISPLAY .....	344
BLUETOOTH SETUP .....	345
SELECTING PHONE MODE .....	346
DIALLING .....	346
ANSWERING/REJECTING CALLS .....	346
PHONEBOOK .....	347
SCRATCHPAD .....	348
CALL REGISTER .....	349
TELEPHONE VOICE CONTROL .....	350
DIALLING A PHONE NUMBER USING VOICE RECOGNITION .....	351
STORING A TELEPHONE NAME/ NUMBER WITH VOICE RECOGNITION .....	352
USING THE VOICE RECOGNITION PHONE DIRECTORY .....	353

## Filling station information

FUEL FILLER FLAP .....	355
REFUELLING .....	355
TYRE PRESSURES .....	356
ENGINE OIL SPECIFICATION .....	356
ENGINE COOLANT SPECIFICATION .....	356