


# Wipers and washers

## WINDSCREEN WIPERS

### CAUTIONS

- ❗ Do not operate the wipers on a dry screen. The drag on the wiper mechanism may cause damage.
- ❗ Before operating in freezing or very hot conditions, ensure that the wipers have not stuck to the glass. The drag on the wiper mechanism may cause damage.
- ❗ Remove any snow, ice or frost, from the screen, around the wiper arms, the wiper blades and from the screen scuttle before operating the wipers. Snow and ice can cause damage to the wiper mechanism if left unclear.




E91447

1. Rain sensor or intermittent variable delay.
2. Normal speed wipe.
3. Pull down and release to operate single wipe.
4. Pull down and hold to operate at fast speed until released.

The wipers and washers will only operate when the ignition is switched on.

**Note:** If the wiper blades become stuck, or jammed, an electronic cut out may temporarily halt the operation of the wipers. If this happens, switch off the wipers and the ignition. Clear any obstructions, and free the wiper blades before switching on the ignition.

### Intermittent variable delay



E91448

With the lever in position 1, rotate the collar clockwise to decrease the interval between wipes. Rotate the collar counterclockwise to increase the interval between wipes.

### Speed dependent mode

When speed dependent mode is configured, the operation of all wiper modes will be affected by the vehicle's speed.

If the vehicle's speed drops below 8 km/h (5 mph) with the wipers operating, the wipers will switch to the next lowest speed. When the vehicle's speed increases to over 8 km/h (5 mph), the original wiper speed setting is restored.



This feature can be enabled or disabled by a Land Rover Dealer/ Authorised Repairer.