

2012 MY Maintenance Schedule Range Rover Sport

NOTE: The maintenance intervals listed are for vehicles operating under normal driving, road, and climatic conditions. More frequent attention may be necessary if the vehicle is subject to routine stop & go driving, extreme temperatures, dusty conditions, off-road driving, or frequent trailer towing. Consult your Land Rover Retailer for more information.

		Maintenance Interval – whichever occurs first (based on expected vehicle display).																																					
SERVICE	Miles x 1000	15	30	45	60	75	90	105	120	135	150	Months	12	24	36	48	60	72	84	96	108	120	Kilometers x 1000	24	48	72	96	120	144	168	192	216	240						
	Change engine oil and replace filter		•	•	•	•	•	•	•	•	•		•																										
VEHICLE INTERIOR																																							
Reset the Service Interval Indicator		•	•	•	•	•	•	•	•	•	•																												
Reset engine oil level indicator		•	•	•	•	•	•	•	•	•	•																												
Check operation of all lights, warning indicators and horn		•	•	•	•	•	•	•	•	•	•																												
Check operation of front/rear wiper washer systems		•	•	•	•	•	•	•	•	•	•																												
Check condition and security of seats and seat belts		•	•	•	•	•	•	•	•	•	•																												
Replace pollen filter		•	•	•	•	•	•	•	•	•	•																												
VEHICLE EXTERIOR																																							
Check condition of wiper blades		•	•	•	•	•	•	•	•	•	•																												
Check operation of all door checks, hood latch, and fuel flap; lubricate door checks		•	•	•	•	•	•	•	•	•	•																												
ENGINE COMPARTMENT																																							
Check battery condition; check / top up electrolyte level		•	•	•	•	•	•	•	•	•	•																												
Check / top up fluid levels (brake, power steering, windshield washer)		•	•	•	•	•	•	•	•	•	•																												
Check / top up coolant level; check specific gravity		•	•	•	•	•	•	•	•	•	•																												
Check condition of accessory drive belt(s) and, if fitted, supercharger drive belt		•	•	•	•	•	•	•	•	•	•																												
Change brake fluid: every 3 years				•																																			
Change engine coolant: every 10 years																																							
Clean debris from auxiliary oil cooler (supercharged vehicles)		•	•	•	•	•	•	•	•	•	•																												
Replace spark plugs																																							
Replace air cleaner elements: naturally aspirated vehicles																																							
Replace air cleaner elements: supercharged vehicles																																							

2012 MY Maintenance Schedule Range Rover Sport

	Maintenance Interval – whichever occurs first (based on expected vehicle display).													
	Miles x 1000		15	30	45	60	75	90	105	120	135	150		
	Months	12	24	36	48	60	72	84	96	108	120	135	150	
SERVICE	Kilometers x 1000	24	48	72	96	120	144	168	192	216	240			
ENGINE COMPARTMENT (CONTINUED)														
Replace accessory drive belt(s)														●
Replace supercharger drive belt (supercharged vehicles): every 7 years													●	
VEHICLE UNDERBODY														
NOTE: Remove all road wheels before inspecting brake components.														
Inspect brake pads for wear, calipers for leaks, and discs for condition		●	●	●	●	●	●	●	●	●	●	●	●	●
Check adjustment of electronic parking brake		●	●	●	●	●	●	●	●	●	●	●	●	●
Inspect tire pressures, condition, and tread depth		●	●	●	●	●	●	●	●	●	●	●	●	●
Inspect exhaust system for leaks, security and damage		●	●	●	●	●	●	●	●	●	●	●	●	●
Inspect for fluid leaks		●	●	●	●	●	●	●	●	●	●	●	●	●
Inspect condition of drivshafts, suspension, and steering boots/gaeters		●	●	●	●	●	●	●	●	●	●	●	●	●
Inspect fuel, hydraulic and fluid pipes, hoses and unions		●	●	●	●	●	●	●	●	●	●	●	●	●
Inspect electrical harnesses, routing and connections		●	●	●	●	●	●	●	●	●	●	●	●	●
Lubricate wheel spigot bore with anti-seize compound; install road wheels to opposite side of same axle (except unidirectional tires, which install on same side)		●	●	●	●	●	●	●	●	●	●	●	●	●
Replace all flexible brake hoses: every 6 years													●	
Replace fuel filter: every 10 years														●
Change transmission fluid and filter: every 10 years														●
Change rear locking differential oil							●							●
Change front and rear axle oil (non-locking differential): every 10 years														●
Change transfer box oil; replace drain and fill plugs and washers														●
Remove debris from between Dynamic Response valve block and chassis		●	●	●	●	●	●	●	●	●	●	●	●	●
Replace filter in Dynamic Response valve block; replace lost fluid														●
Conduct road test: select LOW range gears and drive the vehicle 3 – 4 vehicle lengths, then reselect HIGH range gears		●	●	●	●	●	●	●	●	●	●	●	●	●
If fault lamps are illuminated, interrogate with IDS and report findings		●	●	●	●	●	●	●	●	●	●	●	●	●
Check for any outstanding Recalls or Service Actions		●	●	●	●	●	●	●	●	●	●	●	●	●
Endorse Service Record		●	●	●	●	●	●	●	●	●	●	●	●	●