


AUDIO/VIDEO CONTROLS



SL2005

⚠ WARNING

Do not adjust the touch screen controls, or allow the system to distract the driver, while the vehicle is moving. Driver distraction can lead to accidents, causing serious injury or death.

⚠ WARNING

Sustained exposure to high sound levels can damage your hearing.

1. Press to switch the audio system on/off.

Note: The audio system will operate with the ignition on or off, but will switch off with the ignition. Switch the audio on again if required. The system will remain on for approximately 10 minutes.

Rotate to adjust volume level.

Note: If volume is turned to zero while a CD is playing, the CD will pause play. Play will resume when a greater volume is selected.

2. **SETTINGS.** Press for direct access to the settings menu. When Park Assist is specified, the icon is changed and the button will turn Park Assist on and off. The Settings menu is then accessed via the touch screen.
3. **HOME MENU.** Press for direct access to the Home menu.
4. Touch screen.
5. **MODE.** Press repeatedly to scroll through all audio/video sources.
6. **AUDIO VIDEO.** Press for direct access to the Audio/Video menu.

Audio/Video options can include Radio, HD radio, SDARS, My music, My video and Rear media.

My music consists of CD, Stored CD, MP3, USB, iPod® and AUX.

My video includes CD/DVD, USB and iPod®.

7. CD/DVD loading slot.

The player will accommodate one disc at a time. With the Stored CD player up to 10 CDs can be uploaded onto the Stored CD store.

Only CDDA discs can be loaded into the Stored CD store.

8. Seek up:

- Short press:
 - to auto seek up the frequency to the next radio station,
 - to select the next track on chosen audio source - CD, MP3 etc or
 - to select the next DVD chapter.
- Long press:
 - to activate radio manual seek mode or,
 - to scan forwards through the current audio source track.

With radio manual seek mode activated, further short presses will change the frequency in single increments. A further long press will scan forwards through the current waveband until the button is released.

9. CD/DVD eject button.

10. Seek down:

- Short press:
 - to auto seek down the frequency to the next radio station,
 - to select the previous track or start of current track on chosen audio source - CD, MP3 etc or,
 - to select the previous DVD chapter.
- Long press:
 - to activate radio manual seek mode or,
 - to skip backward through current audio source track.

With radio manual seek mode activated, further short presses will change the frequency in single decrements. A further long press will scan backward through the current waveband until the button is released.

11. **MODE**: Press repeatedly to scroll through all audio/video sources.

12. Press to increase volume.

13. Press to decrease volume.

14. Seek down:

- Short press:
 - to select the previous radio preset or,
 - to select the previous track or start of current track on chosen audio source - CD, MP3 etc.
- Long press:
 - to auto seek down the frequency to the next radio station or,
 - to skip backward through current audio source track.

15. Seek up:

- Short press:
 - to select the next radio preset or,
 - to select the next track on chosen audio source - CD, MP3 etc.
- Long press:
 - to auto seek up the frequency to the next radio station or,
 - to skip forward through a track.

AUDIO SETTINGS

To view the settings menu, press the **SETTINGS** button (2). When Park Assist is specified, the icon is changed and the button will turn Park Assist on and off. The Settings menu is then accessed via the touch screen


Each of the audio/video menu screens will display a **Settings** softkey.

To adjust the audio settings:

- Touch the + or - soft keys to adjust Bass, Treble or Subwoofer levels.
- If surround sound is fitted, touch **DPLIIx**, **DTS Neo:6** or select **Off** to switch surround sound off.

To adjust balance and fade:

- From the **Audio Settings** menu, select **Balance/Fade**.



SJ1080

- Touch the arrows to move the sound focal point to the desired area of the vehicle. Alternatively, drag the focal point cross hairs to a new position.

LOADING DISCS

NOTICE

Do not force the disc into the CD/DVD loading slot.

Do not use irregular shaped CDs or CDs with a scratch protection film or self-adhesive labels attached. It is likely that the disc will not eject and will block the CD mechanism. Such damage to a CD player will not be covered under warranty.

Dual format, dual-sided discs (DVD Plus, CD-DVD format) are thicker than normal discs and consequently playback cannot be guaranteed, and jamming may occur.

NOTICE

The CD unit will play compact discs that conform to the international Red Book standard audio specification. Playback of CDs not conforming to this standard cannot be guaranteed.

NOTICE

Blue Ray and other high definition video format DVD's will not function in this player.

NOTICE

DivX Media Format (DMF) is not supported.

The unit will play compact discs that conform to the international Red Book standard audio specification.

The unit will play Compact Disc Digital Audio (CDDA) discs, MP3, WMA and AAC files. The full infotainment system will also play DVDs.

The unit will play video files recorded in MPEG4 DivX or MPEG4 XVID formats.

The unit will play DivX 3, 4, 5 and 5.2 files.

Version 6 will also play but this depends upon the recording settings.

Acceptable video media recordable discs include; DVD-R, DVD+R, DVD+RW, CD-R, CD+R and CD+RW.

It is recommended that only high quality 12 cm (4.7 in.) circular discs are used.

USB VIDEO

The vehicle system will play video files stored on USB 2.0 devices recorded in MPEG4 DivX 3, 4, 5, 5.2, 6.0 or MPEG4 XVID only.

LICENSING



SJ1580



SJ1534

Manufactured under license from Dolby Laboratories.

Dolby, Pro Logic, and the double-D symbol are registered trademarks of Dolby Laboratories.



SJ1533

Manufactured under license under U.S. Patent #'s: 5,451,942; 5,956,674; 5,974,380; 5,978,762; 6,487,535; 7,003,467 & other U.S. and worldwide patents issued & pending. DTS, the Symbol, and Neo:6 are registered trademarks, & DTS Digital Surround and the DTS logos are trademarks of DTS, Inc. Product includes software. © DTS, Inc. All Rights Reserved.



SJ1550



SJ1551

Manufactured under license under U.S. Patent #'s: 5,451,942; 5,956,674; 5,974,380; 5,978,762; 6,487,535 & other U.S. and worldwide patents issued & pending. DTS and the Symbol are registered trademarks, & DTS 2.0+ Digital Out and the DTS logos are trademarks of DTS, Inc. Product includes software. © DTS, Inc. All Rights Reserved.



SJ1553

DivX Certified® to play DivX® video.

DivX®, DivX Certified® and associated logos are registered trademarks of DivX, Inc. and are used under license.

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, Inc. This is an official DivX Certified device that plays DivX video. Visit www.divx.com for more information and software tools to convert your files into DivX video.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play DivX Video-on-Demand (VOD) content. To generate the registration code, locate the DivX VOD section in the device setup menu.

1. Follow the route, Home Menu - Audio Video - TV/My video - Settings - VOD.

2. An eight digit code will be displayed. This is your unique DivX code. Make a note of this code and keep it for future reference.

Go to <http://vod.divx.com> with this code to complete the registration process and learn more about DivX VOD.

Covered by one or more of the following U.S. Patents: 7,295,673; 7,460,668; 7,515,710; 7,519,274.



SJ1530

Music and video recognition technology and related data are provided by Gracenote®. Gracenote is the industry standard in music recognition technology and related content delivery. For more information, please visit www.gracenote.com.

CD, DVD, Blu-ray Disc, and music and video-related data from Gracenote, Inc., copyright © 2000 to present Gracenote. Gracenote Software, copyright © 2000 to present Gracenote. One or more patents owned by Gracenote apply to this product and service. See the Gracenote website for a non-exhaustive list of applicable Gracenote patents. Gracenote, CDDb, MusicID, MediaVOCS, the Gracenote logo and logotype, and the "Powered by Gracenote" logo are either registered trademarks or trademarks of Gracenote in the United States and/or other countries.

GRACENOTE® END USER LICENSE AGREEMENT

This application or device contains software from Gracenote, Inc. of Emeryville, California ("Gracenote"). The software from Gracenote (the "Gracenote Software") enables this application to perform disc and/or file identification and obtain music-related information, including name, artist, track, and title information ("Gracenote Data") from online servers or embedded databases (collectively, "Gracenote Servers") and to perform other functions. You may use Gracenote Data only by means of the intended End-User functions of this application or device.

You agree that you will use Gracenote Data, the Gracenote Software, and Gracenote Servers for your own personal non-commercial use only. You agree not to assign, copy, transfer or transmit the Gracenote Software or any Gracenote Data to any third party. YOU AGREE NOT TO USE OR EXPLOIT GRACENOTE DATA, THE GRACENOTE SOFTWARE, OR GRACENOTE SERVERS, EXCEPT AS EXPRESSLY PERMITTED HEREIN.

You agree that your non-exclusive license to use the Gracenote Data, the Gracenote Software, and Gracenote Servers will terminate if you violate these restrictions. If your license terminates, you agree to cease any and all use of the Gracenote Data, the Gracenote Software, and Gracenote Servers. Gracenote reserves all rights in Gracenote Data, the Gracenote Software, and the Gracenote Servers, including all ownership rights. Under no circumstances will Gracenote become liable for any payment to you for any information that you provide. You agree that Gracenote, Inc. may enforce its rights under this Agreement against you directly in its own name.

The Gracenote service uses a unique identifier to track queries for statistical purposes. The purpose of a randomly assigned numeric identifier is to allow the Gracenote service to count queries without knowing anything about who you are. For more information, see the web page for the Gracenote Privacy Policy for the Gracenote service.

The Gracenote Software and each item of Gracenote Data are licensed to you "AS IS." Gracenote makes no representations or warranties, express or implied, regarding the accuracy of any Gracenote Data from in the Gracenote Servers. Gracenote reserves the right to delete data from the Gracenote Servers or to change data categories for any cause that Gracenote deems sufficient. No warranty is made that the Gracenote Software or Gracenote Servers are error-free or that functioning of Gracenote Software or Gracenote Servers will be uninterrupted. Gracenote is not obligated to provide you with new enhanced or additional data types or categories that Gracenote may provide in the future and is free to discontinue its services at any time.

GRACENOTE DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NON-INFRINGEMENT. GRACENOTE DOES NOT WARRANT THE RESULTS THAT WILL BE OBTAINED BY YOUR USE OF THE GRACENOTE SOFTWARE OR ANY GRACENOTE SERVER. IN NO CASE WILL GRACENOTE BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES OR FOR ANY LOST PROFITS OR LOST REVENUES.

© Gracenote, Inc. 2009