PARKING AIDS DISABLED

The rear sensors are automatically disabled when a trailer with an approved electrical connector is connected or if a rear fitted accessory is within sensor range.

Note: *Trailers fitted with LED lights will not disable the rear parking aids sensors. When reverse gear is selected, the attached trailer will be detected as an obstacle.*

PARKING AIDS SYSTEM FAULT

If a system fault is detected, a long high-pitched tone will sound and the switch indicator will flash. A message will be displayed in the message centre. Contact your Dealer/Authorised Repairer as soon as possible.

REAR CAMERA

It remains the driver's responsibility to detect obstacles and estimate the vehicle's distance from them when reversing.


Some overhanging objects or barriers which could cause damage to the vehicle, may not be detected by the camera.


When Reverse (**R**) is selected the rear camera provides a wide-angle rear view colour image on the touch screen.

The rear camera display has priority over the Parking aids display. To cancel the camera display at any time, push the **Home Menu** button or touch the back soft key.

To adjust the camera settings while in reverse, touch anywhere on the touch screen to display the user options or select **Extra features**, from the home menu, touch **Cameras** and select **Settings**.

The display also incorporates graphic overlays, indicating vehicle direction, width and proximity to surrounding objects.





SL2272

A. Solid line: The projected path based on current steering wheel position.

B. Dotted line: The safe working width of the vehicle (including exterior mirrors).

C. Tailgate access guideline: Do not reverse beyond this point if tailgate access is required.

D. Parking sensor activation: A coloured area appears, to indicate which rear sensor(s) has been activated.

E. User option. Touch to enable/disable A, B & C.

F. User option. Touch to enable/disable D.

G. User option. Touch to enable/disable Hitch Assist guidance lines. See **107, HITCH ASSIST**.