

## PARKING AIDS DISABLED

The rear sensors are automatically disabled when a trailer with an approved electrical connector is connected or if a rear fitted accessory is within sensor range.

**Note:** Trailers fitted with LED lights will not disable the rear parking aids sensors. When reverse gear is selected, the attached trailer will be detected as an obstacle.

## PARKING AIDS SYSTEM FAULT

If a system fault is detected, a long high-pitched tone will sound and the switch indicator will flash. A message will be displayed in the message centre. Contact your Dealer/Authorised Repairer as soon as possible.

## REAR CAMERA



**It remains the driver's responsibility to detect obstacles and estimate the vehicle's distance from them when reversing.**




Some overhanging objects or barriers which could cause damage to the vehicle, may not be detected by the camera.

When Reverse (**R**) is selected the rear camera provides a wide-angle rear view colour image on the touch screen.

The rear camera display has priority over the Parking aids display. To cancel the camera display at any time, push the **Home Menu** button or touch the back soft key.

To adjust the camera settings while in reverse, touch anywhere on the touch screen to display the user options or select **Extra features**, from the home menu, touch **Cameras** and select **Settings**.

The display also incorporates graphic overlays, indicating vehicle direction, width and proximity to surrounding objects.



SL2272

- A.** Solid line: The projected path based on current steering wheel position.
- B.** Dotted line: The safe working width of the vehicle (including exterior mirrors).
- C.** Tailgate access guideline: Do not reverse beyond this point if tailgate access is required.
- D.** Parking sensor activation: A coloured area appears, to indicate which rear sensor(s) has been activated.
- E.** User option. Touch to enable/disable A, B & C.
- F.** User option. Touch to enable/disable D.
- G.** User option. Touch to enable/disable Hitch Assist guidance lines. See **107, HITCH ASSIST**.