

## PARK ASSIST TROUBLESHOOTING

### **Park assist is not searching for a parking space:**

- The system may not be activated.
- The vehicle may be travelling above 30 km/h (19 mph).
- The sensors may be covered or partly obscured by dirt, mud, ice or snow.

### **Park assist does not offer a certain parking space:**

- The sensors may be covered or partly obscured by dirt, mud, ice or snow.
- The space may not be large enough or there may not be enough space on the opposite side of the vehicle, for the front to swing out during the manoeuvre.
- The vehicle may have been driven too far away (more than 1.5 metres [5 feet]) from the row of parked vehicles.
- The vehicle may have been driven too close (within 41 cm [16 inches]) to the row of parked vehicles.
- The vehicle may have been driven in Reverse (**R**). Park assist will only search for a parking space when the vehicle is in Drive (**D**).
- The approach angle may not be suitable.

### **Park assist has not positioned the vehicle accurately within the space:**

- One or more of the system limitations criteria may have been met. See **135, PARK ASSIST LIMITATIONS**.